



## CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when it is not in use.  
Dust regularly with small brush or vacuum. Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

## NOTICE

Please make sure that you have all parts indicated before you begin assembly of this item.

## Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
<b>A</b>	Left side		<b>1 X</b>
<b>B</b>	Right side		<b>1 X</b>
<b>C</b>	Back		<b>1 X</b>
<b>D</b>	Seat		<b>1 X</b>
<b>E1</b>	Allen bolt L	 M6x70	<b>4 X</b>
<b>E2</b>	Allen bolt S	 M6x35	<b>2 X</b>
<b>E3</b>	Bolt extra	 M6x50	<b>1 X</b>
<b>E4</b>	Allen key		<b>1 X</b>

# SAFAVIEH OUTDOOR LIVING


MODEL # PAT6737

Product Dimension: 21.65"Wx62.99"Dx34.25"H


**Weight capacity : 600 lbs.**

**Warning : Do not stand on the bench**


**Warning : Do not torque bolts / screws**



Before beginning the assembly of the product, make sure all parts are present. Compare the parts with package contents list and hardware contents list. If any parts are missing or damaged, do not attempt to assemble the product. Tool required for assembly (included): Allen key.



Step 1: attach the left side (A) to the back (C) and the seat (D) as shown on the picture by using the Allen bolt (E1). Tighten all with the Allen key (E4).



Step 2: attach the right side (B) to the bench as shown on the picture. Repeat the right side (B) in the same way as step 1. At last, tighten the Allen bolt (E2) by using the Allen key (E3) as shown on the picture.