

NO TOOLS REQUIRED FOR ASSEMBLY



Your box should contain:

- 1 – Rope Hammock with chain assembly.
- 1 – Unassembled Hammock Stand consisting of:
 - 2 – Upright poles with attached S-hook ends.
 - 1 – Center Pole.
 - 2 – Leg assemblies.

****For your convenience plastic pole ends and leg ends are already fitted to their respective poles.****



Assembly Instructions



Step 1. Place both leg assemblies on the ground with the upward curving elbows facing away from each other. Take the center-pole and place on the ground between the two leg assemblies. Locate the holes on each end of the center-pole and face them up. Slide one end of the center pole over the end of one elbow pole on the foot assembly. Push in silver lock-pin (**Figure 1**) and continue to slide pole until the lock-pin pops through the hole. Repeat on the other side.

Step 2. Both upright poles have a pre-attached s-hook and end cap on one end and a lock-pin hole on the other. Take one upright-pole and align the lock-pin hole with the other lock-pin on the elbow pole of the foot assembly. Slide the upright pole over the elbow pole, push lock-pin down (**Figure 1**) and continue to slide pole until the lock-pin pops through the hole (**Figure 2**). Repeat on the other side.

Step 3. Unroll the cotton rope hammock and make sure it is not twisted or tangled. Each end of the rope hammock has an outdoor plated O-ring with a chain attached. Attach one end of the hammock to the assembled hammock stand by placing the last link of the chain over the S-hook on the upright pole. (**Figure 3**) Attach the other end of the rope hammock in similar fashion. (**Note: The initial attachment of the rope hammock to the stand may require more than one person as the rope hammock will likely need to be stretched taught to allow attaching the chain. This is normal as the cotton rope hammock stretches considerably after using the hammock the first couple of times. After the rope hammock has been used it will become much easier to attach.**) Adjust height of hammock by adjusting the link of chain you attach to the S-hook.

**** TIP **** - if rope hammock seems difficult to attach, place your body behind end of stand to prevent stand from sliding, then pull tight by gripping O-ring. Attach chain to stand using your other hand.



Natural Weathering From Sun and Rain Exposure

All hammocks deteriorate over time with exposure to the elements. As a result of exposure, the hammock should be inspected and replaced if needed to ensure safety.

Cotton: The fibers of the cotton rope hammock will darken to a gray color with weather exposure. Fibers will breakdown over time and strength may be lost. For best results, store hammock in cool dry place when not in use to avoid mold or mildew.

Wood: Wood spreader may become bleached with continued exposure. Varnished finished may need to be reapplied.

Caution – Care should always be taken when using your hammock but especially when using your hammock for the first time. Please always use extreme caution when getting into and out of the hammock. Never exceed weight capacity. Never let young children use hammock unaccompanied by an adult. Always inspect hammock before use to assure everything is appropriately attached. Make sure to read and follow hammock care instructions.

Precautionary Measures Before Each Use – Check for loose or untied ropes. Check for fraying at possible wear points (where the ropes pass through the wooden spreader, around the metal ring at each end of the hammock, where the ropes intersect in the body of the hammock bed). Check if ropes are weak by pulling on them. If they appear weak the hammock may be unsafe to use. Check for cracks in the wood. Check the stand to assure it is properly assembled and lies on a level surface. - - - Take care to keep hammock out of direct sun or moisture when not in use. Store in cool dry place.