

**Purchased your product online?**

We would really appreciate it if you can share your experience with others by reviewing our product on the website from which you purchased.



**Owner's Manual**  
Item # FG203LR



# Magical Pond Fogger



**Have Questions or Issues? Need help with assembly?  
Contact us and we will resolve them within 12 hours.**

**Support Hours: M-F 7:30–5:00 (U.S. Pacific Time)**



**Call:**  
**877-460-4511**



**Email:**  
**info@alpine4u.com**



# Limited Warranty Information

Thank you for choosing an Alpine product! We aim to please with our wide range of products including Fountains, Birdbaths, Statuary, Pond Supplies & More. All of our products are constructed from the highest quality materials. In the event that we have not achieved our usual standard of excellence, we will repair or replace, at our discretion, within the warranty period. A valid proof of purchase, with the purchase date clearly indicated, must be provided. Photos of defective merchandise will also be required to help distinguish the actual cause of the defect. Please read below for a detailed description of warranty coverage.

- **Water Damage**  
Alpine products are not manufactured to withstand extreme temperatures. Improper storage that allows water to freeze within a product may cause damage, is considered negligence, and will not be covered under this warranty. The use of "hard water," and/or caustic cleaners, can affect the painted or other finishes. Failure to keep the unit clean, and use of such additives/cleaners, will also void the warranty. Please note: for fountains, it is normal for some splashing to occur and protecting the immediate surfaces is not the responsibility of Alpine Corporation.
- **Paint & Color (Retention and/or Loss)**  
The use of water will cause natural erosion to the color. This area can be touched up using standard paint. The paint is designed to protect the entire finish against breakdown of color. As with any product, all finishes with time will gradually fade and discolor. The warranty will only cover against severe or complete fading, within the first year from date of purchase, with the above exclusion.
- **Procedure/Service**  
Should a warranty/claim be needed, you should contact the retailer from whom you purchased the product. If that is not an option, you can contact Alpine Corporation at [www.alpine4u.com](http://www.alpine4u.com). When contacting Alpine Corporation, you must be prepared to show proof of purchase, provide photographs and any other information needed to validate your claim. This may be necessary to distinguish between a partial or complete replacement of a defective product. The warranty does not cover any items with multiple parts; the warranty will ONLY cover the individual component of the unit/item that may be defective. Replacement parts can be made available to a consumer through the original selling party, or an approved parts retailer. If this is not an option, contact our customer service department. **Item is covered under one year limited warranty from the date of purchase. When requesting replacement parts due to a warranty claim after 30 days of purchase, credit card information will be requested for shipping charges.**
- **Not Covered Under Warranty**  
The limited warranty will NOT cover cases of damages due to:
  1. Damages caused in Transit
  2. Inadequate care and/or neglect
  3. Environmental and/or natural elements
  4. Immersion in water, unless specified
  5. Improper Installation/Storage and/or Maintenance

*This warranty is void if the product has been damaged by accident, misuse, negligence, improper installation and/or modifications have occurred. This includes any and/or all defects arising out of freezing water damage, hard water damage, failure to keep the unit clean and free of harmful additives such as bleach, chlorine, etc.... which affects the paint and/or parts. This warranty also does not cover any additional charges or installation, removal, disposal and/or shipping costs or consequential damage associated with any warranty claim.*

## CONTENTS

Contents .....	1
What's Included .....	2
Features .....	3
Assembling & using your product.....	4
General suggestions for optimum use .....	6
Maintenance .....	6
Replacement Parts .....	7
Caution .....	7
Warranty .....	8

## WHAT'S INCLUDED



Pond Fogger  
1x



Transformer  
1x



Floating Ring  
1x

3. To replace the ceramic disc, you will need a replacement disk which includes a special key that will help unlock the lock ring. With the key, turn the lock ring counterclockwise to access the disc. Replace the disc and then tighten the lock ring by turning it clockwise.

### REPLACEMENT PARTS

### ITEM #

- Replacement 20mm Fogger Disk..... FGDR1
- Replacement Transformer..... RRR118

### CAUTION ⚠

1. Please verify the voltage rate of the transformer with the local power supply before use. Use the supplied specify transformer.
2. Put the transformer, the connector and the controller which attached on the cable in a dry place or use indoor only. Take care that no water can get into the safety transformer, the connector and the controller on the cable along the supply line.
3. The safety transformer will heat up when in operation. Make sure there is sufficient air circulation. Do not cover the housing.
4. Keep electrical appliances out of the reach of children.
5. Never touch the water level sensor.
6. When operating, do not let your body parts such as fingers, touch the ceramic or put on top of it in 4", which is not dangerous but can cause local pains.
7. Never touch the safety transformer and the mains plug with your wet hands.
8. Always withdraw the mains plug before touching the miniature nebulizer or remove it from the water.
9. Avoid placing it in the immediate vicinity of electric appliances or water-sensitive objects because a few water splashes might be produced (but an optimal anti-splash guard is available).


## ASSEMBLING & USING YOUR PRODUCT

Unpack all components carefully. Please check to ensure all parts have been removed from the packaging.

1. Place Fogger into the Floating Ring with the cord going through the bottom of the Floating Ring.



2. Place the Fogger & Floating Ring into a body of water with the cord leading out of the water.
3. Connect the cord from the Fogger into the transformer.



4. Make sure the water level is at  $\frac{3}{4}$ " above the water level Sensor.



### **Alpine Quick Tip**

Water too far above or below the sensor will cause the unit to emit little or no fog.

5. Plug the pump and light cord into your local power supply. Make sure that there is no water around the plug & always keep the power source in a dry place.



## GENERAL SUGGESTIONS FOR OPTIMUM USE


1. The mist unit sends up small jets of water while in operation. Your container should be large enough to prevent water from splashing outside the container. Do not place the unit where water spillage or condensation will cause damage to furniture, electronic products or floors.

2. Use of clean water is recommended. When the water is dirty, change it with clean water in time (dirty water will affect production the mist).
3. Do not use household abrasive cleaners on any part of the mist unit. You may clear it with soft cloth in clean water.


## MAINTENANCE

After operating the mist unit for some time, you may notice a decrease in the amount of mist produced or it may stop working altogether. At that time, you should either clean or replace the ceramic disk.

1. Unplug the unit and remove from water container, clean it with soft cloth in clean water and plug in again. If this doesn't work, then replace the ceramic disk.
2. Unplug the unit and remove from water, clean it with soft cloth in clean water and plug in again. If this doesn't work, then replace the ceramic disk.



## FEATURES



## SPECIFICATIONS

Power Requirements.....Standard Household 120V