

# ASSEMBLY INSTRUCTIONS

ITEM NO:

PUSH BACK RECLINER

A BODY		1PC	 1	 2	<b>RECLINER BACK TENSION ADJUSTMENT</b>  Loosen Loosen If you find pushing back to a reclining position requires more "push" than expected the tension on the springs can be adjusted for ease of push back. Carefully lay the recliner back on the ground to access the bottom. To loosen turn the wing nuts counter clockwise. The manufacturer suggests turning each wing nut one complete turn counter clockwise then test the recliner back push by sitting in the recliner and going to the reclining position. Repeat as needed. DO NOT turn the wing nuts so many times that the spring falls off.  If needed, spring can be removed to eliminate the push back tension .  Thank you for your purchase.
B BACK		1PC			
C LEFT LEG		1PC			
D RIGHT LEG		1PC	 3		
E Bolt	Φ5/16"*2"			6PCS	
F Flat washer	Φ5/16"*16MM			6PCS	
G Spring washer	Φ5/16"			6PCS	
H Allen Key	5MM			1PC	

NOTE: 1: MAXIMUM WEIGHT LIMIT 330LBS