

Disassembly of the EC chairs. (HY014-C)

EC204-EC205

1. Turn chair upside down.
2. Remove 4 bolts that attach the mechanism to bottom of chair.
3. Take small plastic center cover around base. Use straight edge to separate 2 pieces.
4. Set block of wood 4" tall on table.
5. Set cylinder on top of wood block and make sure the base is suspended above the table.
6. Take another block of wood and sit on top of base arms next to cylinder.
7. Hit wood on base arms next to the cylinder and 5-base will drop off.
8. Turn mechanism upright and suspend cylinder off the edge of table.
9. Take straight edge and place under plastic dust cover next to levers and pry up gently. Then go to very front of mechanism and pry gently and dust cover should pop off.
10. Take a small head punch (1/4" wide) place on top of heavy lip of cylinder where it comes through the mechanism.
11. Hit punch with hammer with a good blow. If cylinder does not fall out move punch to opposite side on cylinder and hit punch with hammer.
12. Repeat step 9 until cylinder falls out

******Caution cylinder may fall on feet.******