



PIONEER INDUSTRIES, INC.
3325 S. Garfield Ave.
Commerce, CA 90040
(800) 338-9468
www.pioneerind.com

INSTALLATION

Tools:



Adjustable Wrench



Plumbers Putty



Teflon Tape



Rags

Model Number: 3BR2X0, 3BR3X0, 3AM100



Warnings and Notes:


Check with local plumbing code requirements before installation.

This product should be installed by a local listed plumber.


Do not use plumbers putty on threads.

Installation Steps:


Two Handle Lavatory Faucet




(1) Shut off water supplies. Remove old faucet. Clean mounting surface in preparation for new faucet.




(2) Apply plumbers putty under the base gasket. Place the faucet in position on the sink. Install washer on shanks and tighten with locknut.



(3a) when using ball-nose flexible supplies to connect faucet to water supply valves, slip coupling nut onto flexible supply. Ball-nose coupling will go partially into shank. Tighten coupling nut (DO NOT OVERTIGHTEN). Install opposite end according to manufacturer's instruction for both tubes.




(3b) when using stainless steel braided faucet supply hose; this faucet requires one end of the supply hose to have a 1/2" female IPS connection. The other end of this supply hose must match the thread on the water supply valve under your sink. Once you've identified the required size, carefully follow the manufacturer's installation instructions for each hose.




(4) Important: After installation is complete, remove aerator. Turn water supplies on and allow both hot and cold water to run at least one minute each. While water is running, check for leaks. Turn off water and replace aerator.


Pop-up Drain Installation:




(1) Remove pop-up flange from body




(2) Place a ring of putty on the bottom of flange.




(3) Insert pop-up flange through drain hole and attach flange to body. Ensure the pop-up outlet faces towards the back of the sink. Tighten the locknut securely with a wrench. Do not overtighten.




(4) Remove the excess putty. Connect the trap (check manufacturer's instructions for installation)



(5) Remove pivot rod nut from pop-up body, ensure the washers is in place, insert pivot rod, tighten pivot rod nut back to pop-up body.



(6) Push pivot rod down, insert drain plug carefully. Test to ensure drain plug works properly.




(7) Connect lift rod strap to pivot rod by using clip. Tighten the thumbscrew to connect lift rod strap to pop-up lift rod.

Exploded Drawing : (For 3BRXX0)

* Note: Please specify finish/color when ordering.

	ITEM #	DESCRIPTION
1	X-4900042C, H*	Button-C, H (For 3BRX00, 3BRX10)
2	X-4900061	Handle Screw (For 3BRX00, 3BRX10, 3BRX20)
3	X-4900062C, H*	Button-C, H (For 3BRX20)
4	X-4900002	3/32" Allen Screw (For 3BRX30)
5	X-4200090	Spout Snap Ring (For 3BR3X0)
6	X-4900012	Spout O-Rings (For 3BR3X0)

	ITEM #	DESCRIPTION
A	X-1900009C,H*	Lever Handle-C, H (For 3BRX00)
A	X-1900010C,H*	Porcelain Lever Handle-C, H (For 3BRX10)
B	X-1900011C,H*	Porcelain Cross Handle-C, H (For 3BRX20)
C	X-1900012C,H*	Beaux Lever Handle-C, H (For 3BRX30)
D	X-4900037	Bonnet Nut
E	X-4900038	Gasket
F	X-3900002C,H	Ceramic Stem-Cold,Hot
G	X-4900081*	1.5 GPM Aerator (For 3BR2X0)
H	X-4300018	Base Gasket
I	X-4900008	Mounting Kit
J	X-4900004	Supply Nuts
K	X-4900095*	1.5 GPM Aerator (For 3BR3X0)
L	X-6300007*	Brass Pop-Up Drain Assembly




For more care information or trouble shooting inquiries
about your Pioneer product, please call:
Pioneer Industries, Inc. (800) 338-9468
Monday-Friday 8AM to 8PM EST (5AM to 5PM PST)
www.pioneerind.com

Exploded Drawing : (For 3AM100)

* Note: Please specify finish/color when ordering.

	ITEM #	DESCRIPTION
A	X-1300004C,H*	Lever Handle-C, H
B	X-4900037	Bonnet Nut
C	X-4900038	Gasket
D	X-3900004C,H	Ceramic Stem-Cold,Hot
E	X-4300018	Base Gasket
F	X-4900008	Mounting Kit
G	X-4900004	Supply Nuts
H	X-4900091*	1.5 GPM Aerator
I	X-6300005*	Brass Pop-Up Drain Assembly
1	X-4900042C, H*	Button-C, H
2	X-4900036	Handle Screw



For more care information or trouble shooting inquiries
about your Pioneer product, please call:
Pioneer Industries, Inc. (800) 338-9468
Monday-Friday 8AM to 8PM EST (5AM to 5PM PST)
www.pioneerind.com