

INSTALLATION

PIONEER INDUSTRIES, INC. 3325 S. Garfield Ave Commerce, CA 90040 (800) 338-9468 www.pioneerind.com

Model Number: 2AM600, 2MT600



Teflon Tape

Rags

Power Drill

Warnings and Notes:

Check with local plumbing code requirements before installation. This product should be installed by a local listed plumber. **Do not use plumbers putty on threads.**

Installation Steps:

Wallmount Pot Filler



(1) Confirm the 1/2" IPS/NPT threaded inlet pipe nipple must be kept with a length of 1/2" from the finished wall.

Tools:

Adjustable Wrench



(6) Remove the 3/32" Allen screw



(2) After wall is finished install the pot filler to the 1/2" IPS/NPT threaded inlet pipe nipple. Do not fully tighten.



(7) Carefully screw the pot-filler into inlet pipe nipple using adjustable wrench to fully tighten the pot filler. Ensure the notches on the faucet align with the 3/32" Allen screw.Level the pot filler. Tighten the 3/32" Allen screw.



(3) Level the pot-filler. Mark the drilling hole location on the finished wall. Space remove the pot filler.



(8) Place the escutcheon in correct position. Tighten the 1/16" Allen screw



(4) Drill the four 3/32" holes on the premarked location



(9) Make sure the pot filler spout swivels smoothly. Place a bucket underneath of the pot-filler. Remove the aerator.



(10) Turn on inlet water supply. Make sure all the connections are secure. Open both handles. Flush and allow water to run at full flow for at least one minute. Turn off water and replace the aerator.



(5) Apply Teflon tape to thread end of inlet pipe nipple before installing the mounting bracket. Put the mounting washer on the wall and drill the 3/32" hole on the same location as wall. Ensure the mounting washer is behind the mounting bracket to form the watertight seal. Install the mounting bracket with the mounting screws supplied with faucet. Tighten the mounting screws.

Exploded Drawing (2AM600)

* Note: Please specify finish/color when ordering.

	1	
	ITEM #	DESCRIPTION
Α	X-1200010*	Lever Handle
В	X-4200093*	Handle Sleeve
С	X-4200067*	Handle Escutcheon
D	X-3200004H	Ceramic Cartridge
Е	X-4900041*	2.0 GPM Aerator
F	X-1200009*	Lever Handle
G	X-4200064*	Escutcheon
Н	X-5200010	Mounting Kit
1	X-4900040	1/16" Allen Wrench
J	X-4900024	3/32" Allen Wrench
1	X-4900042P*	Handle Button-Plain
2	X-4900043	Handle Screw
3	X-4200065	Handle Screw
4	X-4900039	1/16" Allen Screw
5	X-4900002	3/32" Allen Screw



PIONEER

For more care information or trouble shooting inquiries about your Pioneer product, please call: **Pioneer Industries, Inc.** (800) 338-9468 Monday-Friday 8 AM to 8 PM EST (5 AM to 5 PM PST) www.pioneerind.com

Exploded Drawing (2MT600)

* Note: Please specify finish/color when ordering.

		1
	ITEM #	DESCRIPTION
А	X-1200018*	Lever Handle
В	X-3200004H	Ceramic Cartridge
С	X-4200153	Gasket
D	X-4900041*	2.0 GPM Aerator
E	X-1200021*	Lever Handle
F	X-4200158*	Escutcheon
G	X-5200010	Mounting Kit
Н	X-4900040	1/16" Allen Wrench
1	X-4900024	3/32" Allen Wrench
1	X-4900002	3/32" Allen Screw
2	X-4400073*	Hole Cover
3	X-4900039	1/16" Allen Screw





For more care information or trouble shooting inquiries about your Pioneer product, please call: **Pioneer Industries, Inc.** (800) 338-9468 Monday-Friday 8 AM to 8 PM EST (5 AM to 5 PM PST) www.pioneerind.com