### CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.

The use of steam or water-based cleaners may cause excessive shrinking or staining. NOTICE

\* Please make sure that you have all parts indicated before you begin assembly of this item

item
\* This item should be assembled on a soft surface to prevent scratching the finish
during assembly

\* This item may require periodic tightening

## Parts List and Hardware List

#### QUANTITY PIECE PICTURE DESCRIPTION Headboard A 1X • В Metal Leg 2X 0 Nut H1 4X H2 Washer 12X Big bolt M8 x 30mm NWWWWW НЗ 4X Small bolt M6 x 25mm H4 4X

The hardware that is needed to connect the headboard to the bed frame is included. Please note that our headboard legs are compatible to most standard bedframes. Our headboards <u>DO NOT</u> include a mounting bracket\*.





#### PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 10 minutes.






#### Step 1

Remove the legs (B) from the back of the headboard (A) by unscrewing the 2 big cross bolts (H3) and 2 washers (H2). The bolts and washers need to be re-used to attach the legs in the correct position in Step 2.




# Step 2

Attach the two legs (B) to the headboard (A) using 4 big cross bolts (H3) and 4 washers (H2). The vertical slots at the lower part of the leg must be facing the outside of the bed.





### ASSEMBLY INSTRUCTIONS APPLICABLE FOR ALL SAFAVIEH HEADBOARDS. THE DESIGN OF THE HEADBOARD IN THE DRAWINGS MAY VARY FROM YOUR ACTUAL HEADBOARD, BUT ASSEMBLY IS THE SAME ON ALL MODELS AND SIZES.



Step 3 The hardware needed to connect the headboard to the bed frame are 4 small bolts (H4), 8 washers (H2), and 4 nuts (H1) L

Step 4 Attach the legs of the headboard (B) to the bed frame or mounting bracket by fixing them together through the 2 holes in the bed frame and the vertical slot in the leg using 4 small bolts (H4), 8 washers (H2) and 4 nuts (H1)