CARE AND MAINTENCE

Wipe clean with a soft, dry cloth. The seat board can be cleaned with a mild cleaner. Test the cleaning method on a hidden area before using them over the entire area.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item.
- * This item should be assembled on a soft surface to prevent scratching the finished product during assembly.
- * This item may require periodic tightening.
- * Do not tighten bolts until completely assembled.


Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
А	CHAIR BACK		1 X
В	SEAT CUSHION		1 X
С	ARMREST-RIGHT		1 X
D	ARMREST-LEFT	7	1 X
E	R/FRONT LEG		1 X
F	L/FRONT LEG		1 X
G	R /BACK LEG	•	1 X
Н	L/BACK LEG		1 X
T	R/STRETCHER	_	1 X
J	L/STRETCHER	_	1 X
K	FRONT STRETCHER	/	1 X
L	BACK STRETCHER	—	1 X
H1	BOLT Ø5/16"*2"	(—	10 X
H2	L-WRENCH	=	1 X
H3	SCREW	DESTRIES	8 X
H4	BOLT Ø5/16"*2-1/2"	—	4 X



Model# FOX6221

Product Dimensions:22-1/2"W*23"D*39-1/2"H




PREPARATION


Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time:10 minutes.


Tools Required for Assembly (included):Wrench.




Step 1: Assemble seat cushion (B) with chair back (A).Using L-wrench (H2) to lock with 4*bolts (H4).




Step 2: Assemble legs (E & G) with R/stretcher (I). Then, assemble legs (F&H) with L/stretcher (J).




Step 3: Attach the assembled right legs (E&G) to right armrest(C).Then assemble right armrest (C) with seat cushion (B). Using L-wrench (H2) to lock with 5*bolts (H1).



Step 4:
Assemble front
stretcher (K) with
R/front leg (E). Then,
assemble back
stretcher (L) with
R/back leg (H).



Step 5:
Attach the assembled left legs (F&H) to left armrest(D) together with front / back stretchers (K&L).
Then,assemble left armrest (D) with seat cushion (B).Using L-wrench (H2) to lock with 5*bolts (H1).



Step 6: Lock the stretchers tight with legs by using 8*screws (H3).