




MODEL No. 5APD 10914

INSTALLATION MANUAL






В


TOOLS REQUIRED

- Plumb Line
- Pencil
- Phillips Head Screwdriver
- 8mm Drill Bit
- 10mm Routing Drill Bit
- Wrench
- Level
- Tape Measure
- Power Drill

INCLUDED IN KIT

| Α | Door Roller Hardware | x2 |
|---|----------------------|----|
| В | 78" Rail | x1 |
| С | Wall Bracket | x5 |
| D | 2.5mm Allen Key | x1 |
| Е | Door Stop | x2 |
| F | Anti-Jump Disk | x2 |
| G | Routed Floor Guide | x1 |
| Н | Floor Anchor | x2 |
| П | ST4.2x25 Screw | x2 |
| J | M8x30 Wall Anchor | x5 |
| K | M8x60 Bolt + Washer | x5 |
| L | M8x90 Bolt | x5 |







Minimum door overlap on guide is 4-3/4"

To obtain maximum weight capacity, all fasteners must be mounted into solid wood studs or wall blocking or mounted to a header board.

Consult a structural engineer if you have questions about what type of wall blocking is required.




Find the centerline of the track. Using a level, mark a horizontal line twice the door width long. Mark the bracket screw locations into the wall blocking. Attach the wall portion of the brackets as shown.




Attach the rail to the wall brackets using a wrench to fasten the bolts as shown.






Drill out holes in the door using a 10mm routing drill bit as pictured. The bottom of the door should be routed at this time in order to accept the floor guide.




Attach the anti-jump disks to the tops of the door.



Attach the doors to the rails making sure that the anti-jump disks are engaged to avoid a serious accident.

Plumb the door and mark the positions of the floor guides. Mount the floor guides to the floor.





Adjust the door stops accordingly using the provided 2.5mm Allen key.