			1-4
Tools required			
⊕ ⇐━━━━━━━━━━━━	θ	Ø8mm	

Installation instruction

- Review instructions carefully before installation
- Installation should be completed by a suitably qualified person
- Please dispose of packaging in a responsible manner



Plug in installtion



2-4

Hard wired installtion



3-4

Operation and maintenance instruction

- After installation, connect the electric power and turn on the switch. The indicator light will show red and the towel warmer will start to work.
- Turn off the switch when the towel warmer is not in use. The indicator light will turn off and the towel warmer will stop working.
- Clean the towel warmer with a soft dry towel.
- This unit has been designed to run continuously.

Voltage :120VAC Rated Frequency :60HZ-55W

Warning:

1.Please DO NOT connect the unit to electricity supply before completely reading and understand the product manual.

2. This product is intended only for domestic use and do NOT put the product into the water or in sauna room, shower cubicle and steam room.

- 3. This product is only for textile fabrics that washed by water.
- 4. In order to avoid a hazard for infant or child, this appliance should be installed at the place that is at least 39 inches above the floor.
- 5.If the wiring was damaged, it must be replaced by manufacturer or service agent or a qualified person to avoid electric shock hazard
- 6.The surface temperature is high when towel warmer is working, PLEASE BE CAREFUL!
- 7.For safety, please do NOT sit, stand, lean against, hang on the product or collide in avoid any damage or collision on the surface of product and influence the function or life of product.
- 8.Elderly and physically / mentally disabled persons should be supervised when this towel warmer is in operation
- 9.If there's any problem, please turn off and contact the supplier where it was purchased. WARNING SHOCK HAZARD. Please do not attempt to make repairs to the electrical part of this product.

10.Please DO ensure that your hand is dry when unplugging the cord.