

installation instructions:

PVC CORBEL

SAFETY INSTRUCTIONS

Make sure to use the correct tools recommended.

Wear safety goggles.

Follow fixture, power tools, and paint manufacturers' instructions and users manuals.

Use common sense and follow good construction practices.

Corbels are not load bearing, decorative use only.

TOOL & MATERIAL CHECKLIST

- | | |
|---|---|
| <input type="checkbox"/> electric drill | <input type="checkbox"/> wood blocks |
| <input type="checkbox"/> drill bit for pilot hole | <input type="checkbox"/> elastomeric adhesive |
| <input type="checkbox"/> countersink bit | <input type="checkbox"/> caulking gun |
| <input type="checkbox"/> lag screws & washers | <input type="checkbox"/> mechanical fasteners |
| <input type="checkbox"/> acrylic caulk | |
| <input type="checkbox"/> sand paper | |

IMPORTANT INFO

Because of the wide variety of sizes, weights, applications, and building codes these installation instructions are to be used as a reference and not as the recommended methods. The installer should be sure to use common sense and good construction practices. If there is any uncertainty about how to install this product consult a professional.

INSTALL INSTRUCTIONS:

Hollow Corbel

1. Attach wood blocks to surface with screws.
2. The top and back pieces of corbel will easily "slip" over wood blocking strips.
3. Screw through side of bracket into wood blocks to properly secure.
4. Use acrylic caulk to seal edges of bracket against surface after installation.
5. Fill in any holes with caulk and smooth the surface with finger.
6. Let caulk dry. Once dry, lightly sand with extra fine sandpaper.
7. Touchup bracket with paint as needed.

Solid Corbel

1. Lay the corbel face down on a soft surface.
2. Apply a 1/2" bead of adhesive caulk all the way around the back edge of the bracket.
3. When pressing the bracket up against the surface, some adhesive caulk will seep out. Smooth excess caulk around the bracket with a finger and apply extra caulk that is needed to fill in any gaps.
4. Wipe off any excess adhesive caulk with a sponge or damp rag.
5. Screws may be used for added support. If used, fill in any holes with caulk and smooth the surface with a finger. Let any excess caulk dry. Once dry, lightly sand with extra fine sandpaper.
6. Touchup bracket with touchup paint as needed.

EXAMPLE DIAGRAM:

