


How to Measure & Size

bifold doors



A - The first step is to measure the width of the door opening. Measure from the inside of the finished door jamb on one side to the inside edge on the other side.

Measure the opening near the top, middle and bottom, and use the narrowest width measured.

B - The second step is to measure the height of the door opening. Measure from the inside of the finished door header to the top of the finished floor covering.

Measure the opening near the left, middle and right, and use the shortest length measured.



Measure the finished door opening, not the door itself.

Bifold doors will be prefitted for standard sized openings. The right size door for you is the one with the whole number measurements closest (*but not larger than*) the width and height of your opening. The door will be made slightly smaller to allow for it to operate properly (*see table below*).

For openings of 48", 60" and 72" widths, two (2) bifolds doors are used:

- 48" width use two (2) 24" bifolds
- 60" width use two (2) 30" bifolds
- 72" width use two (2) 36" bifolds

There's no need to find a door with exactly the same prefitted dimensions as the door being replaced. Different manufacturers use slightly different specs.

WIDTHS	
Nominal	Actual
24"	23-11/16"
30"	29-11/16"
36"	35-11/16"

Bifold door thickness, generally 1" or 1-3/8", is a matter of design, style and aesthetics.

HEIGHTS	
Nominal	Actual
78"	76-3/4"
80"	78-3/4"
96"	94-1/2"