




Item # : TW60MRF  
Assembly Instructions




*Please visit our website for the most current instructions, assembly tips, report damage, or request parts. **[www.walkeredison.com](http://www.walkeredison.com)***


Revised 05/2017

# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .











- VII. Power tools should not be used to assemble this product .



# Parts List




# Hardware List

A		M10 x 35	Wooden dowel	18 pcs
B		M6*90	Bolt	4 pcs
C		M6*35	Bolt	8 pcs
D			Wood button	4 pcs
E			Barrel nut	4 pcs
F			Adjuster	4 pcs
G		M4	Wrench	1 pc
H			Glue tube	1 pc


*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

## Step 1




Insert wooden dowel (A) into parts (3).

## Step 2




Insert barrel nut (E) into parts (3).

## Step 3




Use wrench (G) to secure legs (2) to parts (3) with bolt (B).

## Step 4




Use wrench (G) to secure legs (2) to top panel (1) with bolts (C).

## Step 5



Place wood button (D) and insert adjuster (F) into legs (2) as per diagram.

## Step 6



## Final Assembly