



ASSEMBLY INSTRUCTIONS




NOTE TO CUSTOMERS:

- For ease and speed of assembly we recommend that before you commence each step of the assembly that you identify all the parts required to complete that step.
- We recommend that where possible you allow sufficient space to assemble the item as close as possible to the place where it will be once assembled.
- For the protection of your furniture we recommend that the product is placed on protected surfaces during assembly to prevent any damage.
- During assembly do not over tighten, as this may damage the product.
- Please ensure you retain all the product packaging until the item completely assembled.
- Please periodically check all fittings and re-tighten as necessary.
- Never allow any liquids to remain on your furniture as absorption can cause the wood to warp or the finish to de-laminate.
- It is recommended that this item should be assembled by two adults.


To insert a cam lock: (Please read below instructions before assembling)




1. Insert cam screw into hole as shown in diagram A .




Make sure not to insert the cam screw:
Too deep as shown in figure B as this will cause the
cam screw to be misaligned and unable to
interlock properly.




Also avoid inserting the cam screw too close to the
surface of the hole as shown in figure C, as this will
cause the cam lock to be too loose, and not interlock
properly.



2. Connect the panels together.



3. When inserting the cam lock make sure the arrow
of the cam lock faces the cam screw.















4. To tighten the cam lock turn the cam lock clockwise
90-180 degree or until the arrow is facing opposite
the place cam lock was inserted.

**NOTE: DO NOT USE AN AUTOMATIC
SCREWDRIVER TO TIGHTEN CAM LOCKS.**








Note:

- Read these instructions carefully before assembling.
- Tools required : Phillips screwdriver, flat screwdriver.
- Find a clean, smooth area on which to work , such as a carpet, in order to avoid scratching the wood surfaces.
- Wait to dispose of the packing material until assembly is complete and all parts and hardware are accounted for.
- Two or more people might be required for assembly.

Part List



<p>A1</p> <p>Quantity of 1</p>  <p>Top Panel</p>	<p>A2</p> <p>Quantity of 1</p>  <p>Side Panel (Left)</p>	<p>A3</p> <p>Quantity of 1</p>  <p>Side Panel (Right)</p>	<p>A4</p> <p>Quantity of 1</p>  <p>Bottom Panel</p>
<p>A5</p> <p>Quantity of 2</p>  <p>Divider</p>	<p>A6</p> <p>Quantity of 1</p>  <p>Top Divider</p>	<p>A7</p> <p>Quantity of 1</p>  <p>Back Panel</p>	<p>A8</p> <p>Quantity of 3</p>  <p>Drawer Front Panel</p>
<p>A9</p> <p>Quantity of 6</p>  <p>Drawer Side Panel</p>	<p>A10</p> <p>Quantity of 3</p>  <p>Drawer Back Panel</p>	<p>A11</p> <p>Quantity of 3</p>  <p>Drawer Bottom Panel</p>	<p>A12</p> <p>Quantity of 4</p>  <p>Leg</p>


Hardware List

<p>B1</p> <p>Quantity of 6</p>  <p>Wood Dowel</p>	<p>B2</p> <p>Quantity of 8</p>  <p>Cam-bolt</p>	<p>B3</p> <p>Quantity of 25</p>  <p>Screw</p>	<p>B4</p> <p>Quantity of 4</p>  <p>Screw</p>
<p>B5</p> <p>Quantity of 6</p>  <p>Screw</p>	<p>B6</p> <p>Quantity of 3</p>  <p>Bolt and Knob</p>	<p>B7</p> <p>Quantity of 2</p>  <p>Wood Dowel</p>	

Assembly instruction

Step :1


B1  4pcs
B2   4sets



Assemble Dividers (A5) to Side Panels (A2&A3) using Wood Dowels (B1), Cam-bolts (B2) and Cam-locks (B2).




Step :2


B4  1pcs
B7  2pcs



Assemble Top Divider (A6) to Top Panel (A1) using Wood Dowels (B7) and Screws (B4).



Step :3


B1		2pcs
B2	 	4sets



Assemble Top Panel (A1) to Side Panels (A2&A3) using Cam-Bolts (B2) & Cam-Locks (B2) and Wood Dowels (B1).

Step :4


B1		2pcs
B4		4pcs



- 1). Insert Back Panel (A7) into the grooves on the back of Side Panels (A2&A3) and Top Panel (A1).
- 2). Then assemble Bottom Panel (A4) to Side Panels (A2&A3) using Wood Dowels (B1) and Screws (B4).



Step :5


B5  6pcs



Tighten Back Panel (A7) to Side Panels (A2&A3) using Screws (B5). Then attach Legs (A12) to the bottom of Bottom Panel(A4).


Step :6

B3  24pcs
B6  3sets











- 1), Assemble Drawer Side Panels (A9) to Drawer Back Panel (A10) using Screws (B3).
- 2), Insert Drawer Bottom Panel (A11) into the grooves on Drawer Side Panels (A9) and Drawer Back Panel (A10).
- 3), Attach Knob (B6) to Drawer Front Panel (A8) with included bolt..
- 4), Attach Drawer Front Panel (A8) to Drawer Side Panels (A9) using Screws (B3).

Step :7



Insert drawers into this unit.

APPENDIX: Dimension of Hardwares in this AI.

<p>B1</p>  <p>Wood Dowel</p>	<p>B2</p>  <p>Cam-bolt</p>	<p>B3</p>  <p>Cam-Lock</p>	 <p>Screw</p>
<p>B4</p>  <p>Screw</p>	<p>B5</p>  <p>Screw</p>	<p>B6</p>  <p>Bolt</p>	<p>B7</p>  <p>Wood Dowel</p>