


**W** Walker<sup>®</sup>  
Edison  
furniture company

Item # : B42STC  
Assembly Instructions




*Please visit our website for the most current instructions, assembly tips, report damage, or request parts. [www.walkeredison.com](http://www.walkeredison.com)*


Revised 05/2017

# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .






- VII. Power tools should not be used to assemble this product .





# Hardware List


A		Ø15x11	Cam lock	16 pcs
B		Ø6*35	Cam bolt	16 pcs
C		Ø8x30	Wooden dowel	29 pcs
D		Ø6x50	Bolt	12 pcs
E			Plastic wedge	6 pcs
F		Ø3x17	Flat-head screw	6 pcs
G		Ø4x32	Flat-head screw	3 pcs
H		Ø20	Sticker	16 pcs
J		M4	Wrench	1 pc
K			Glue tube	2 pcs



Philips head screwdriver required for assembly  
(not included)


*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

# Step 1




Inserts dowels (C) into parts (1,2,7,8,9) and screw cam bolts (B) into parts (2,3,4,9) as shown in the diagram.

# Step 2




Inserts dowels (C) into parts (5,6,11) as shown in the diagram.

## Step 3




Attach parts (7,8) to part (9) as shown in the diagram. Carefully place cam locks (A) into parts (7,8) and tighten using a screwdriver.

## Step 4




Secure supports (12) to bottom panel (10) using bolts (D) as shown in the diagram.

## Step 5





Secure dividers (5,6,11) to bottom panel (10) using bolts (D) as shown in the diagram.

## Step 6





Slide back panel (13) into place carefully.

# Step 7





Attach parts (1,3,4) to part (2) as shown in the diagram. Carefully place cam locks (A) into part (2) and tighten using a screwdriver.

# Step 8




Place top assembly onto lower frame as shown in the diagram. Insert cam locks (A) as shown and tighten using a screwdriver.

## Step 9




Insert wedges (E) to the back panel and secure using screws (F) as shown in the diagram.

## Step 10




Cover cam locks using stickers (H) as desired.

## Step 11



Place fabric bins (14) and cushion (15) into place as shown.

## Step 12



## Final Assembly