



# ASSEMBLY INSTRUCTIONS




## NOTE TO CUSTOMERS:

- For ease and speed of assembly we recommend that before you commence each step of the assembly that you identify all the parts required to complete that step.
- We recommend that where possible you allow sufficient space to assemble the item as close as possible to the place where it will be once assembled.
- For the protection of your furniture we recommend that the product is placed on protected surfaces during assembly to prevent any damage.
- During assembly do not over tighten, as this may damage the product.
- Please ensure you retain all the product packaging until the item completely assembled.
- Please periodically check all fittings and re-tighten as necessary.
- Please never allow any liquids to remain on your furniture as absorption can cause the wood to warp or finish to de-laminate.
- It is recommended that this item should be assembled by two adults.


## To insert a cam lock: (Please read below instructions before assembling)




1. Insert cam screw into hole as shown in diagram A .




Make sure not to insert the cam screw:  
Too deep as shown in figure B as this will cause the  
cam screw to be misaligned and unable to  
interlock properly.




Also avoid inserting the cam screw too close to the  
surface of the hole as shown in figure C, as this will  
cause the cam lock to be too loose, and not interlock  
properly.



2. Connect the panels together.



3. When inserting the cam lock make sure the arrow  
of the cam lock faces the cam screw.



4. To tighten the cam lock turn the cam lock clockwise  
90-180 degree or until the arrow is facing opposite  
the place cam lock was inserted.

NOTE: DO NOT USE AN AUTOMATIC  
SCREWDRIVER TO TIGHTEN CAM LOCKS.

### Note:

- Read these instructions carefully before assembling.
- Tools required : Phillips screwdriver, flat screwdriver.
- Find a clean, smooth area on which to work , such as a carpet, in order to avoid scratching the wood surfaces.
- Wait to dispose of the packing material until assembly is complete and all parts and hardware are accounted for.
- Two or more people might be required for assembly.



## WARNING:













**Serious or fatal crushing injuries can occur from furniture tip-over.**

**To help prevent tip-over:**




















- Place heaviest item in the lowest drawers.
- Unless specifically designed to accommodate, do not set TVs or other heavy objects on top of this product.
- Never allow children to climb or hang on drawers, doors or shelves.
- Never open more than one drawer at a time.(OR)
- Do not defeat or remove the drawer interlock system.

Use of tip-over restraints may only reduce, but not eliminate the risk of tip-over.





## Hardware List


 <p>(a): Camlock 22sets</p>	 <p>(b): Wood dowel 18pcs</p>	 <p>(c): Knob with bolt 3sets</p>
 <p>(d): Magnet 2sets</p>	 <p>(e): Stopper 1pc</p>	 <p>(f): Screw 1pc</p>
 <p>(g): Shelf Support 8pcs</p>	 <p>(h): Screw 8pcs</p>	 <p>(i): Door Pin 4pcs</p>
 <p>(j): Screw 22pcs</p>	 <p>(k):Anchor with Screw 1set</p>	 <p>(l):Anti-tip kit 1set</p>

## Part List

			
A:Top Panel 1pc	B:Left Side Panel 1pc	C:Right Side Panel 1pc	D:Bottom Panel 1pc
			
E:Left Divider 1pc	F:Right Divider 1pc	G: Shelf 1pc	H:Adjustable Shelf 2pcs
			
I:Cross Panel 3pcs	J:Cross Panel 2pcs	K:Left Door 1pc	L:Right Door 1pc
			
M:Cross Bar 1pc	N:Drawer Front Panel 1pc	O:Drawer Side Panel 2pcs	P:Drawer Back Panel 1pc
			
Q:Drawer Bottom Panel 1pc	R:Center Feet 1pc	S:Back Panel 1pc	



# Step 1


d:		2pcs
f:		1pc
e:		1pc
j:		4pcs



- 1): Attach Magnets (d) to Dividers (E & F) using Screws (j), please note holes are pre-drilled.
- 2): Attach Stopper (e) to Cross Bar (M) using Screw (f), please note holes are pre-drilled.





# Step 2


a:		2sets
b:		2pcs



Assemble Cross Bar (M) to Dividers (E&F) using Camlocks(a) and Wood Dowels (b).





# Step 3


a:			4sets
b:			2pcs



Assemble Shelf (G) to Dividers (E&F) using Camlocks (a) and Wood Dowels (b).


# Step 4



a:			4sets
b:			2pcs



Assemble Bottom Panel (D) to Dividers (E&F) using Camlocks (a) and Wood Dowels (b).


## Step 5





a:		8sets
b:		8pcs

Assemble Side Panels (B&C) to Shelf (G) and Bottom Panel (D) using Camlocks (a) and Wood Dowels (b).

## Step 6




a:		4sets
b:		4pcs

Assemble Top Panel (A) to Side Panels (B&C) using Camlocks (a) and Wood Dowel (b).

## Step 7


j:  22pcs



Attach Back Panel (S) to Side Panels (B&C), Shelf (G), Bottom Panel (D) and Dividers (E&F) using Screws (j). Then tighten Center Feet (R) to the bottom of Bottom Panel (D).

## Step 8

i:  4pcs




Insert Door Pins (i) into holes on Doors (K&L) as drawing shown above.



## Step 9


c:  2sets



- 1): Connect Door (K) to the Bottom Panel (D) as above Fig.1.
- 2): Press the upper pin on Door (K) see Fig.2. and insert Door (K) carefully into the cabinet with the upper pin popping up into the holes of Shelf (G).
- 3): Attached Knobs (c) to Door (K) using included bolts.
- 4): Repeat above steps to assemble Left Door (L).

## Step 10


g:  8pcs



Insert Shelf Supports (g) into holes on Side Panels (B&C), Dividers (E&F). Then put Shelves (H) onto Shelf Supports (g).

## Step 11


h:  4pcs



- 1): Assembled Drawer Side Panels (O) to Drawer Back Panel (P) using Screws (h).
- 2): Insert Drawer Back Panel (Q) into grooves on Drawer Side Panels (O).


## Step 12

c:  2sets  
h:  4pcs




Attach Knob (c) to Drawer Front Panel (N) using included bolts, then assemble Drawer Front Panel (N) to Drawer Side Panels (O) using Screws (h).

## Step 13




Cross the cross bars (J) to (I) as above drawing shown .

## Step 14











Insert Cross Bars (I & J) and Drawer in the center of this unit.



k:  1set  
l:  1set

For your safety, please attached this unit to the wall by Anchor with screws (k) and Anti-tip kit (l).

## APPENDIX: Dimension of Hardwares in this AI.

<p>a.</p>  <p>Cam-Lock</p>	<p>b.</p>  <p>Wood Dowel</p>	<p>c.</p>  <p>Bolt for Handle</p>	<p>f.</p>  <p>Screw</p>
<p>h.</p>  <p>Screw</p>	<p>j. &amp; d.</p>  <p>Screw</p>	<p>k.</p>  <p>Screw</p>	<p>l.</p>  <p>Screw</p>