




BUTTERFLY-S

SHOWER DOOR INSTALLATION INSTRUCTIONS

PLEASE REVIEW THIS ENTIRE MANUAL PRIOR TO INSTALLATION



left-pivot door installation shown

MODEL #s

SHDR-4532741-##

SHDR-4536741-##

= finish

01 - Chrome

04 - Brushed Nickel

06 - Oil Rubbed Bronze

09 - Satin Black

IMPORTANT!

DreamLine® reserves the right to alter, modify or redesign products at any time without prior notice for the purpose of product improvement and customer experience. Please refer to the model's web page on **DreamLine.com** for the latest technical drawings, installation manuals, warranty information or additional product details.

Do Not Return Product to the Store. Contact DreamLine® with any questions



Questions?

Please Call **DreamLine** Customer Support: **1-866-731-2244**
Hours of Operation M-F 8AM - 6PM EST

Support@DreamLine.com





Record the following purchase information for your records or in the event you need to contact DreamLine®:

Purchase Order
Number _____

Store/Vendor
Purchased From _____

Installation Date _____

OD Number
(optional) _____
located on the shipping box or label
if available.

Installed By: _____

SKU Number _____

Table of Contents

Section Title	Page #
Warnings and General Preparation	2
Model Specific Preparation	3
Adjustable Wall Profile System	4
Tools	5
Detailed Diagram of Shower Door Components	6
Parts List	7-8
Installation Steps	9-29
Vertical Vinyl Seal Installation	18
Knob Handle Installation	23
Securing the Adjustable Profile System	26
Profile Clip Installation	23
Bottom Deflector Vinyl Installation	27
Product Maintenance	30
Troubleshooting	31
Factory Parts Information	32-33

Symbol Legend

 **TIP** - for ease of installation.


 **NOTE** - take note of special feature; additional information.

 **REQUIRED** - requires special attention; signifies a warning.

 **CORRECT** - recommended.

 **INCORRECT** - not recommended.

Average Installation Time





IMPORTANT

- DreamLine® reserves the right to alter, modify or redesign products any time without prior notice for product improvement and customer experience. Please refer to the model's web page on **DreamLine.com** for the latest technical drawings, installation manuals, warranty information or additional product details.
- This product should be installed by someone familiar with the construction requirements for this type of project and the care necessary for the safe installation and operation of the product.
- The safety of any installation is the responsibility of the installer.
- Professional installation recommended. (*All Models*)
- Professional installation required. (*Enigma Series*)
- To prevent damage or serious injury, Do Not lean against the installed panel/door/glass.
- To prevent damage or serious injury: Do Not attempt to lift or move a heavy lite of glass alone. Use an assistant and/or a professional grade glass suction cup.
- The installation of some models may require drilling down into the threshold. Contact the manufacturer of the base, tub, or threshold material with any questions regarding the drilling of holes into their product.
- All drawings in this installation manual are for illustrative purposes only and are not drawn to scale.

TEMPERED GLASS WARNING

- Your Shower Door Glass Could Shatter Without Warning if Improperly Installed or Mishandled
- Do Not install or operate a shower door if the glass has chipped corners, slivered edges or is otherwise damaged and/or has been dropped or banged into a hard surface such as tile, marble or glass.
- **The main causes of tempered glass breakage are:**
 - Improper handling, storage or installation
 - Misuse/abuse
 - Lack of maintenance
 - Failure to replace damaged glass
 - **Improper handling during storage, unpacking and installation:**
 - Corners and edges are the most susceptible area to damage on a lite of tempered glass and should be protected and handled with care during storage, unpacking, installation and operation. A concentrated point of pressure or impact with a surface harder than itself may cause the tempered glass to shatter. The tempered glass may release immediately, within several hours or even days later.
 - **Incorrect installation of door hardware, rollers, hinges, channels, stopper or glass:**
 - Improper installation may include: loose hardware and/or lack of proper gaskets between the hardware and glass. Additionally, improper alignment of guide rails, wall profiles or other hardware during installation or operation may place stress on the glass edges and cause it to break.
 - This product must be installed by a professional and experienced installer familiar with the safe handling of tempered glass.
 - **Improper use of this product:**
 - Aggressively opening or closing the door may cause trauma to the glass, which can lead to breakage. This may occur immediately or hours or even days later.
 - **The shower door hardware and glass should be inspected periodically:**
 - Instruct the homeowner how to perform a periodic inspection of the shower hardware and glass - some minor adjustments may be necessary based upon the use (or misuse) of the shower door. Ensure that the hardware remains tight and that the door alignment and operation are correct. Any adjustments should be made upon discovery to prevent damage to the product.
 - Additional considerations should be given to the installation of frameless tempered glass products in households with young children or an elderly person due to an increased chance of improper handling. In such cases, alternatives such as shower curtains or grab bars should be considered.

GENERAL PREPARATION

- After opening all boxes and packages, read this introduction carefully. Check that all the items are included in the package by marking off the components on the “**Detailed Diagram of Product Components**” page. Examine all boxes and packages for shipping damage. If the unit has been damaged, has a finishing defect, or is missing parts; please contact our Customer Support department within 3 business days of the delivery date. **Please note that DreamLine® will not replace any damaged products or missing parts free of charge after 3 business days or if the product has been installed.** Please contact DreamLine® if you have any questions.
- **Please note that you should refer to your local building codes with questions on installation compliance standards. Building and plumbing codes may vary by location, and DreamLine® is not responsible for code compliance standards for your project and will not accept any returns.**
- If this unit is going to be installed in a new construction, install all the required plumbing and drainage before installing the shower. **Use a competent and licensed (if required by local code) plumber for all plumbing installation.**
- Make sure that prior to beginning the installation, the surfaces are leveled and solid and will be able to support the total weight of the unit. Also make sure the walls are at right angles. Irregular installation surface level, radius corners or improper angle of side walls will result in serious problems for your installation. Please note that some adjustments and drilling will be necessary during the installation process.
- Protect all primary surfaces of the product during installation. Never set your glass down directly onto a tile floor. Leave corner protectors in place until it is necessary to remove them. Always use a piece of wood or cardboard to protect the bottom edge and corners of the glass prior to and during installation.
- This unit must be installed upon a finished threshold and against finished walls.
- *DreamLine® shower doors are not designed to be installed into a fiberglass surround due to the radius corners and lack of a solid surface to mount the hardware.*

WARNING: TO AVOID THE RISK OF DAMAGE OR INJURY:

- **Follow all recommendations and requirements as shown in the installation instructions.**
- Perform a thorough inspection of the glass and all parts for any damage prior to installation. Any damage to tempered glass can cause breakage. **Do Not install damaged glass!**
- Do Not install or operate a shower or tub door if the glass has chipped corners, slivered edges or is otherwise damaged. Do Not install or operate a shower or tub door that has been dropped or banged into a hard surface such as tile, marble or glass.
- **CAUTION:** Contact with any hard surface can damage tempered glass and cause it to shatter.
- This product uses tempered glass. Glass cannot be cut after it has been tempered. **Do Not attempt to cut tempered glass.**
- DreamLine® Glass Shower doors, Tub doors, Inline panels, and Return panels can shatter due to improper handling or lack of maintenance. Conduct periodic inspections of glass and all parts for possible damage, missing or loose parts.
- Always wear proper safety equipment such as: safety goggles, work gloves and appropriate footwear during the installation process.
- **WARNING. Risk of leakage and/or damage.** Follow all instructions regarding the application of silicone sealant or caulk. Allow 24 hours for the sealant to cure before the initial use of the shower or tub product. Follow the silicone manufacturer's recommendations regarding the use of their product.
- **Thoroughly read these instructions before installing or using this product.**
- **Leave this manual for the end-user of the product.**



This product should be installed by someone familiar with the construction requirements for this type of project and the care necessary for the safe installation and operation of the product.





Model Specific Preparation






REQUIRED:


3/4" Out-of-Plumb Adjustment per wall profile; Verify threshold and walls with a level




Threshold must be level




This model has a **3/4" (19.05mm) adjustable wall profile system** for out-of-plumb wall conditions within model size when placed into the finished opening. For more information, see **Adjustable Wall Profile System** on page 4.



DO NOT attach the Handle to the Door Glass until instructed. **DO NOT** use the handle to lift the glass during installation. This may result in damage to the glass and/or serious personal injury. Always use an assistant and/or a professional-grade glass suction cup when handling heavy glass panels.



This door is reversible for right- or left-hinge door installation. The left-hinge door installation is shown throughout this manual. For the right-hinge door installation, simply begin on the opposite wall and reverse the orientation of the installation steps shown.





Professional installation by two installers is recommended for this shower door.







Adjustable Wall Profile System



The Glass Profiles can be adjusted within the Wall Profiles for overall width or to correct out-of-plumb conditions within the model size. Screw them together after making final adjustments.




NOTE
3/4" Max Adjustment ID Groove



Tools




Level




Tape Measure



Pencil



#2 Phillips Screwdriver



100% Silicone



Power Drill



Drill Bit
Ø1/8"
(3.2mm)



Drill Bit
Ø3/16"
(4.7mm)




Drill Bit
Ø1/4"
(6mm)




Drill Bit
Ø5/16"
(8mm)



#2 Phillips Driver Bit



Hacksaw



OR Miter Saw



Metal File



Razor Knife




Painter's Tape




Safety Glasses




Work Gloves



Professional-grade Glass suction cup (optional but recommended)



Carpenter's Square



Soft Head Hammer



Verify that the correct model size has been ordered; measure the finished opening **before** proceeding with the installation.

Confirm that the finished walls are plumb and the threshold is level and pitched into the shower area.

Use a good quality waterproof, mildew-resistant 100% silicone.

Cover the shower/tub drain with tape prior to installation to prevent the loss of screws or small parts.

Use a type of drill bit that is appropriate for drilling into the finished surface material.




Unpack your unit carefully and inspect it. Lay it out and identify all parts using the **Detailed Diagram** on **page 6** and the included packing list in this manual as a reference. Before discarding the carton, check for small hardware bags that may have fallen to the bottom of the box. If any parts are damaged or missing, please contact DreamLine® for replacement. The shipping boxes may contain extra parts not used in your model configuration.



Retain these installation instructions for future reference.













Detailed Diagram of Shower Door Components



left-pivot door installation shown


for Model #s:
 SHDR-4532741-##
 SHDR-4536741-##
01/04/06/09

Parts List



Parts List


13



ST4.0x10mm
Pan Head Screw

x10


14



T-Vinyl seal
(pre-installed into Item #04)

x2


15



Bottom Deflector Vinyl

x2


16



Vertical Vinyl Seal

x1


17



Top Pivot
Roller Assembly

x1


18



Top Pivot Assembly

x1


19



Bottom Pivot
Roller Assembly

x1


20



Bottom Pivot Assembly

x1


21



Top
Stopper Assembly

x1


22



Decorative Cover
(with washer)

x10

23



M5x12
Button Head Screw

x2

24



3mm Allen Wrench

x1

Installation Steps

1

Top
*at model height
_____ "

Middle
_____ "

Bottom
_____ "




Fig 1

Tools Needed



* The standard model height for this door is 73-7/8"

2

Bottom Finished Opening _____"

(-) 1/16" (1.5mm) =

(L) finished cut length _____"




Fig 2a

Bottom Finished Opening (-) 1/16" (1.5mm) = Finished Cut Length (L)




Fig 2b




Fig 2c




Use a metal file to deburr the cut end




The **Bottom Guide Rail (#01)** fits wall-to-wall and can be cut from either end.

Parts Needed



Tools Needed




3



Top Finished Opening _____"

(-) 1/16" (1.5mm) =

(L) finished cut length _____"



Top Finished Opening (-) 1/16" (1.5mm) = Finished Cut Length (L)




Use a metal file to deburr the cut end




The **Top Guide Rail (#02)** fits wall-to-wall and can be cut from either end.

Parts Needed



Tools Needed



4





Fig 4




Before marking the position of the **Bottom Guide Rail (#01)** on the threshold, ensure the rail is parallel with the outside edge of the threshold.

Parts Needed



Tools Needed



5








Fig 5



From the outside Bottom Guide Rail mark, measure **1-1/8" (28.75mm)** towards the inside of the shower and draw a plumb line from the threshold up **72-1/2" (1841.5mm)**. This represents the centerline of the **Wall Profiles (#03)** and **Guide Rail Brackets (#07)**.








Fig 6

NOTE Make sure the **Guide Rail Bracket (#07)** is located at the **72-1/2" (1841.5mm)** line before marking the holes on the centerline.




TIP Confirm the **Wall Profile (#03)** is plumb with a level before marking the location of the holes for drilling.

Parts Needed







Tools Needed







7

NOTE

Install the **Wall Profiles (#03)** so that the **holes** face towards the inside of the shower.



NOTE The **Glass Profile (#04) Max Adjustment ID Groove** must face the inside of the shower!



NOTE

Install the **Glass Profiles (#04)** so that the **T-Vinyl Inserts (#14)** are exposed

Fig 7


NOTE

- **If a stud is present behind the wall:**
drill a $\text{Ø}3/16''$ (4.76mm) hole to the stud, drill a $\text{Ø}1/8''$ (3.2mm) pilot hole into the stud and use **ST4.0 x 40mm Pan Head Screws (#05)** to attach the **Guide Rail Bracket (#07)** and **Wall Profile (#03)**.
- OR
- **If no stud is present behind the wall:**
drill a $\text{Ø}5/16''$ (8mm) hole and insert the **Wall Anchors (#06)** and use the **ST4.0 x 40mm Pan Head Screws (#05)**.



Repeat **Steps 5-7** to install the opposite **Wall Profile (#03)**, **Guide Rail Bracket (#07)** and **Glass Profile (#04)** before proceeding onto the next step.

Parts Needed



Tools Needed



8

Bottom Guide Rail Installation





Fig 8

Enlarged View Figure 8.1



Remove any debris from the **Bottom Guide Rail (#01)** before installing the **Bottom Pivot Assemblies (#19/20)**!



Loosen the set-screws to install into the rail, then tighten and back off a 1/4 +/- turn so it can be moved into position within the **Bottom Guide Rail (#01)**.



Secure the **Bottom Guide Rail (#01)** to the threshold with painter's tape until the silicone cures.

left-pivot door installation shown



It is strongly recommended to allow the silicone beneath the Bottom Guide Rail (#01) to cure for at least 30 minutes before installing the door!




Ensure the **Bottom Stopper Assembly (#11)** faces towards the **Bottom Pivot Roller Assembly (#19)**.



*For the right-pivot door installation, the orientation of the cone-tipped set screw within the **Bumper Stop Assembly (#11)** must be reversed before installation.

Parts Needed




Tools Needed



9a

NOTE

Maintain even spacing between the door glass during the hinge installation.



TIP


Ensure the orientation of both Hinge Assemblies (#09) are the same.

TIP


Ensure the orientation of both Hinge Assemblies (#09) are the same.

Fig 9a
left-pivot door installation shown

Parts Needed



Tools Needed



9b

Vertical Vinyl Seal Installation





Fig 9b



Attach the **Vertical Vinyl Seal (#16)** to the inside edge of the **Door Glass (#08)** that is on the same side as the shower head so that the flexible fin is pointing away from the water source.

Parts Needed



10a




Fig 10a

NOTE

To prevent drifting from the intended mark: Use a center punch or **drill an $\text{\O}1/8''$ (3.75mm) pilot hole first**, then drill a **$\text{\O}1/4''$ (6.35mm) hole**.

10b






Fig 10b

Parts Needed



Tools Needed



10c



Ensure the **Top Stopper Assembly (#21)** faces towards the **Top Pivot Roller Assembly (#17)**!













Fig 10c
left-pivot door installation shown




Remove any debris from the **Top Guide Rail (#02)** before installing the **Top Pivot Assemblies (#17/18)**!

Parts Needed



Tools Needed






32" (812.8mm) model
SHDR-4532741-##

Fig 11




36" (914.4mm) model
SHDR-4536841-##



The **Glass Profiles (#04)** must be installed at the correct distance for the model size. Once correctly positioned and plumb, proceed to the next step to attach the **Glass Profiles (#04)** to the **Wall Profiles (#03)**.

Tools Needed



Securing the Adjustable Profile System






Fig 12

NOTE

Include the washers when installing the **ST4.0×10mm Pan Head Screws (#13)** and **Decorative Caps (#22)**.



Parts Needed



Tools Needed



Profile Clip Installation






Fig 13

Parts Needed



Tools Needed



14



It is strongly recommended to allow the silicone beneath the Bottom Guide Rail (#01) to cure for at least 30 minutes before installing the door




Fig 14a




Fig 14b



Align the **Top and Bottom Pivot Assemblies** approximately **1-1/8" (28mm)** from the **Glass Profiles (#04)** before installing the door into the opening.





Fig 14c

left-pivot door installation shown





Fig 15
left-pivot door installation shown

Tools Needed



3mm

Knob Handle Installation





Fig 16
left-pivot door installation shown

NOTE


Extra gaskets are supplied with the **Knob Handles (#10)** to be used to align the inside and outside knobs with one another if necessary.

Parts Needed



Bottom Deflector Vinyl Installation

Fig 17a



NOTE

Use a with a razor utility knife to cut the **Bottom Deflector Vinyl (#15)** to fit between the bottom **Hinge (#09)** and **Bottom Pivot (#19/20) Assemblies** on both doors.






Fig 17b
left-pivot door installation shown




Install the **Bottom Deflector Vinyl (#15)** onto the Door Glass with the fin facing towards the outside of the shower.



Parts Needed



Tools Needed






Fig 18
left-pivot door installation shown



After final adjustments, install all of the screw covers onto the **Top and Bottom Hinges (#09), Top Pivot Roller (#17), Top Pivot (#18), Bottom Pivot Roller (#19) and Bottom Pivot (#20) Assemblies**

NOTE

The surfaces need to be clean and free of debris before applying silicone.





Fig 19
left-pivot door installation shown



Allow 24 hours for the silicone to cure before using shower.

Tools Needed



Product Maintenance

BASES and BACKWALLS: To ensure long lasting life for your acrylic back walls: wipe them off after each use with a soft cloth. To clean the acrylic back walls use non-abrasive sprays or cream based cleaners. Avoid the use of aerosol spray cleaners. Never use abrasive cleansers, metal brushes or scrapers that could permanently scratch or dull the surface.

GLASS: To ensure long lasting life for your glass shower products: wipe them off after each use with a soft cloth. Rinse and wipe off the glass using either a soft cloth or a squeegee to prevent soap buildup and water spots (Hard water can etch the surface of the glass over time if left to dry). To prevent scratching the surface: never use abrasive cleaners or cleaning products that contain scouring agents. Never use bristle brushes or abrasive sponges that may scratch the surface of the glass.

HARDWARE: To ensure a long lasting finish: wipe off all metal parts after each use with a soft cloth. Do not use abrasive cleaners or cleaning products containing ammonia, bleach or acid. If accidentally used, rinse the surface as soon as possible to prevent damage to the finish (peeling or corrosion). After cleaning the polished finishes, rinse thoroughly and wipe dry with a soft clean-cloth.

Clean stainless steel surfaces at least once a week. When applying stainless steel cleaner or polish to stainless steel hardware, work with the grain (not across the grain). Never use an abrasive sponge or cloth, steel wool or wired brush as these may permanently scratch the surfaces.



To maximize the life of your door, it is important to regularly inspect the glass and other hardware for misalignment, proper attachment, and/or damage. Contact DreamLine® with any questions or concerns.

BUTTERFLY-S Maintenance Checklist

- Check that the unit is stable, operates smoothly and that the installation is secure.
 - Profile Clips** secure the **Wall/Glass Profiles** to the **Bottom Guide Rail**
- Confirm that all screws/bolts are tight.
- Confirm that the **Top** and **Bottom Stopper Assembly** set screws are tight
- Confirm that all vinyl gaskets are present to prevent glass-to-metal contact
- Confirm that all vinyl seals are intact (replace if missing or damaged to prevent leakage.)
- Inspect exposed and concealed glass edges for damage
 - Damaged Glass Must be Replaced**
- Inspect silicone for gaps. Replace silicone as necessary to prevent leakage.

Troubleshooting

Problem/Symptom	Suggested Solution	Page(s)
Missing Parts	<ul style="list-style-type: none"> •Check all shipping/packaging material for missing parts/components. •If not found, contact DreamLine Customer Support [1-866-731-2244] to order factory part replacement. 	—
Top (#02) or Bottom (#01) Guide Rail cut too short	<ul style="list-style-type: none"> •If the Top (#02) or Bottom (#01) Guide Rail is cut too short during installation, contact DreamLine Customer Support [1-866-731-2244] to order a factory part replacement. 	—
Door is not operating smoothly	<ul style="list-style-type: none"> •Check the Bottom Deflector Vinyls (#15) for proper trimming and installation •Inspect the Top (#02) and Bottom (#01) Guide Rails to ensure there is no damage to the tracks or obstructing debris present. •Inspect the Top (#21) and Bottom (#11) Stopper Assemblies and ensure the rubber bumper is facing towards the Top (#17) and Bottom (#19) Pivot Roller Assemblies •Make sure that the top and bottom pivot assemblies are aligned with each other. Some adjustment may be necessary. 	16; 20;24; 27
Knob Handle (#10) makes contact with the opposite Door Glass (#08) when the door is in the open position	<ul style="list-style-type: none"> •Adjust the positions of the Top (#21) and Bottom (#11) Stopper Assemblies: Loosen the set screws and adjust both stoppers to a proper location that prevents contact between the handle and the glass when the door is fully opened 	16; 20; 23; 25



Prior to contacting DreamLine® Customer Service, please have the following information readily available:

- Purchase Order Information
 - Name, PO Number, Dealer/Vendor Name, etc.
- SKU/Model Number (see Pages 32-33)
- Factory Part Information (see Pages 32-33)

Factory Parts Information

BUTTERFLY-S {SHDR-4532741-##}		FACTORY PARTS INFORMATION	
ITEM #	FACTORY PART NUMBER	ITEM DESCRIPTION	QTY
01	042480 1 1-0800 / 042480 4 1-0800 / 042480 6 1-0800 / 042480 9 1-0800	Bottom Guide Rail	1 pc
02	042510 1 1-0800 / 042510 4 1-0800 / 042510 6 1-0800 / 042510 9 1-0800	Top Guide Rail	1 pc
03	042490 1 1-1808 / 042490 4 1-1808 / 042490 6 1-1808 / 042490 9 1-1808	Wall Profile	2 pcs
04	042500 1 1-1808 / 042500 4 1-1808 / 042500 6 1-1808 / 042500 9 1-1808	Glass Profile	2 pcs
05	091107	ST4.0 x 40 Pan Head Screw	12 pcs
06	07552148	Wall Anchor 8mm (5/16in)	12 pcs
07	0712 1 169 / 0712 4 169 / 0712 6 169 / 0712 9 169	Guide Rail Bracket	2 pcs
08a	010038001	Door Glass 2	1 pc
08b	010038002	Door Glass 1 [with hole for Handle]	1 pc
09	0742 1 060 / 0742 4 060 / 0742 6 060 / 0742 9 060	Glass-to-Glass Hinge for 6mm (1/4 in) glass	2 pcs
10	0722 1 087 / 0722 4 087 / 0722 6 087 / 0722 9 087	Back-to-Back Square Knob Handle	1 pc
11	0700 1 230 / 0700 4 230 / 0700 6 230 / 0700 9 230	Stopper Assembly (bottom)	1 pc
12	07121168	Profile Clip for Glass Profile	2 pcs
13	091101	ST4.0 x 10 Pan Head Screw	10 pcs
14	063020000-1785	T-Vinyl Seal	2 pcs
15	063069060-0339	Bottom Deflector Vinyl	2 pcs
16	063005060-1717	Vertical Vinyl Seal	1 pc
17	0732 1 034 / 0732 4 034 / 0732 6 034 / 0732 9 034	Top Pivot Roller Assembly	1 pc
18	0702 1 233 / 0702 4 233 / 0702 6 233 / 0702 9 233	Top Pivot Assembly	1 pc
19	0732 1 033 / 0732 4 033 / 0732 6 033 / 0732 9 033	Bottom Pivot Roller Assembly	1 pc
20	0702 1 232 / 0702 4 232 / 0702 6 232 / 0702 9 232	Bottom Pivot Assembly	1 pc
21	0700 1 231 / 0700 4 231 / 0700 6 231 / 0700 9 231	Stopper Assembly (top)	1 pc
22	0755 1 011 / 0755 4 011 / 0755 6 011 / 0755 9 011	Decorative Cover and Washer	10 pcs
23	095211	M5 x 12 Button Head Screw	2 pcs
24	098003	3mm Allen Wrench	1 pc

BOLD digit indicates finish: **1** = Chrome; **4** = Brushed Nickel;
6 = Oil Rubbed Bronze; **9** = Satin Black

Contact Support@DreamLine.com for Part replacement, installation assistance or additional information.

Complete **Warranty** information is available on DreamLine.com.

Factory Parts Information

BUTTERFLY-S {SHDR-4536741-##}		FACTORY PARTS INFORMATION	
ITEM #	FACTORY PART NUMBER	ITEM DESCRIPTION	QTY
01	042480 1 1-0902 / 042480 4 1-0902 / 042480 6 1-0902 / 042480 9 1-0902	Bottom Guide Rail	1 pc
02	042510 1 11-0902 / 042510 4 11-0902 / 042510 6 11-0902 / 042510 9 11-0902	Top Guide Rail	1 pc
03	042490 1 11-1808 / 042490 4 11-1808 / 042490 6 11-1808 / 042490 9 11-1808	Wall Profile	2 pcs
04	042500 1 11-1808 / 042500 4 11-1808 / 042500 6 11-1808 / 042500 9 11-1808	Glass Profile	2 pcs
05	091107	ST4.0 x 40 Pan Head Screw	12 pcs
06	07552148	Wall Anchor 8mm (5/16in)	12 pcs
07	0712 1 169 / 0712 4 169 / 0712 6 169 / 0712 9 169	Guide Rail Bracket	2 pcs
08a	010038003	Door Glass 2	1 pc
08b	010038004	Door Glass 1 [with hole for Handle]	1 pc
09	0742 1 060 / 0742 4 060 / 0742 6 060 / 0742 9 060	Glass-to-Glass Hinge for 6mm (1/4 in) glass	2 pcs
10	0722 1 087 / 0722 4 087 / 0722 6 087 / 0722 9 087	Back-to-Back Square Knob Handle	1 pc
11	0700 1 230 / 0700 4 230 / 0700 6 230 / 0700 9 230	Stopper Assembly (bottom)	1 pc
12	07121168	Profile Clip for Glass Profile	2 pcs
13	091101	ST4.0 x 10 Pan Head Screw	10 pcs
14	063020000-1785	T-Vinyl Seal	2 pcs
15	063069060-0390	Bottom Deflector Vinyl	2 pcs
16	063005060-1717	Vertical Vinyl Seal	1 pc
17	0732 1 034 / 0732 4 034 / 0732 6 034 / 0732 9 034	Top Pivot Roller Assembly	1 pc
18	0702 1 233 / 0702 4 233 / 0702 6 233 / 0702 9 233	Top Pivot Assembly	1 pc
19	0732 1 033 / 0732 4 033 / 0732 6 033 / 0732 9 033	Bottom Pivot Roller Assembly	1 pc
20	0702 1 232 / 0702 4 232 / 0702 6 232 / 0702 9 232	Bottom Pivot Assembly	1 pc
21	0700 1 231 / 0700 4 231 / 0700 6 231 / 0700 9 231	Stopper Assembly (top)	1 pc
22	0755 1 011 / 0755 4 011 / 0755 6 011 / 0755 9 011	Decorative Cover and Washer	10 pcs
23	095211	M5 x 12 Button Head Screw	2 pcs
24	098003	3mm Allen Wrench	1 pc

BOLD digit indicates finish: **1** = Chrome; **4** = Brushed Nickel;
6 = Oil Rubbed Bronze; **9** = Satin Black

Contact Support@DreamLine.com for Part replacement, installation assistance or additional information.

Complete **Warranty** information is available on DreamLine.com.



TEL: 866-731-2244
FAX: 866-857-3638
DREAMLINE.COM



For more information on DreamLine® Shower Doors and Enclosures please visit [DreamLine.com](https://www.DreamLine.com)