



English /Español / Françaish

www.parrotuncle.com



Installation & Operating Instructions for the Parrotuncle Owner's Installation ,Manual

WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

Safety Information

- 1. To reduce the risk of an electrical blow, electricity on the protective switch or the safety box went out before starting.
- 2. All wiring must correspond to the NASI/NFPA 70-1999 National Electric Code and local electrical regulations. The electrical installation must be carried out by a qualified and approved electrician.
- 3. The connection box and support construction must be assembled safely and 35 pounds (15.9 kilos) must be able to transport reliably. Use only output boxes listed with labeling

"Accepted for fans with a weight of £ 35 (15.9 kilos) or less."

- 4. The fan must be installed with a minimum distance of 2.1 m (7 feet) from the posterior edge of the wings to the floor.
- 5. Do not operate the reverse switch if the fan wings are moving. You have to turn off the fan and stop the wings before reverse the direction of the wing.
- 6. Do not place objects on the road to wings.
- 7. To avoid lesions or damage to the fan and other objects, be careful if you work on the fan or clean it.
- 8. Electrical diagrams only serve as a reference. The lighting rates that are not delivered with the fan must be listed and marked with the valve model that will be installed for use. The switches must be general use switches UL. Take into account the instructions for the appropriate installation included in the lighting rates and the switches.
- 9. After the electrical connections have been made, the size staircase must be turned up and carefully push to the plug box. The cables must be distributed in such a way that the ground connected driver and the device head are next to the socket.

All fixing screws must be verified before installation and, if necessary, followed.



WARNING: To reduce the risk of injury, knife supports (also known as flanges) cannot be folded during installation or after installation. Do not put any object on the path of wings.



WARNING: Remove rubber motor attacks at the bottom of the fan before mounting the wings or try the engine.



WARNING: To avoid the risk of a fire or an electrical blow, this fan should not be used with a semiconductor speed controller.



WARNING: To avoid a possible electric shock, turn off the current in the main security box before wiring. If you feel that you do not have enough knowledge or experience in electrical wiring, communicate with a license electrician.



WARNING: Electrical diagrams only serve as a reference. The optional use of an lighting rate must be on the list and marked with this fan for use.



WARNING: To reduce the risk of fires, electrical discharges or injuries, assemble the device in a socket that with the inscription accepted for fans with a weight of £ 35) or less. It is marked and use the screws supplied with the plug.

TECHNICAL INFORMATION

SKU	Nominal voltage	Nominal output (motor)	Light
F6371110V	110-120V AC	32W	1*LED MAX.18W
F637SN110V	110-120V AC	32W	1*LED MAX.18W

Installation & Operating Instructions for the

Parrotuncle Owner's Installation, Manual

WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER



Parrot Uncle



F6371110V Installation & Operating Instructions for the Parrotuncle Owner's Installation ,Manual WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER





5

6

F6371110V & Operating Instructions for the

Installation & Operating Instructions for the Parrotuncle Owner's Installation ,Manual WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

As shown in the figure, the main fan is hung on the hanger plate,

Lock the 4 blade holder components onto the motor





F6371110V Installation & Operating Instructions for the Parrotuncle Owner's Installation ,Manual

WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER





Installation & Operating Instructions for the Parrotuncle Owner's Installation, Manual WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

Remote controller GENERAL INF ORMATION



LIGHT MUST BE KEPT AT THE ON POSITION

FAN MUST BE KEPT AT THE HIGH SPEED



F6371110V Installation & Operating Instructions for the Parrotuncle Owner's Installation ,Manual WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

2. OPERATING TRANSMITTER : 0 0 0 0 0 0 0 0 A. Install 2032 3 volt battery. ON/OFF -) ON/OFF Light ON/OFF FAN OFF (To prevent damage to transmitter, remove the battery if not used for a long time). -0-Fan Speed + Warm Light \bigtriangleup B. Store the transmitter away from excessive heat or -0- \bigtriangledown Warm white Light Fan Speed humidity. C. Operating the buttons on the panel of the transmitter. White Light <u>``</u> R Foward/Reverset (FIG.3) (FIG.3) Ð D. Setting the codes on the receiver: The Learn Key must be pressed with in 5 seconds, \bigcirc after pressing the Power button. EARN If not, please press the Power button to restart. Battery: CR2032 3V Keep pressing the button LEARN key in excess of 3 second it becomes a LEARN status. The receiver can remember the last codes status . The ceiling fan light flash two times. (FIG.4) 0

(FIG.4)