# 2000 ANELLO COLLECTION **TOILET PAPER HOLDER**

MODERN TRANSITIONAL

sales@preferredbathinc.com www.preferredbathinc.com (336) 904-6248

PART NUMBERS

2008-рс-т

2008-BN-T

2008-мв-т



FINISH

POLISHED CHROME

BRUSHED NICKEL

MATTE BLACK

# MODERN TRADITIONAL TOILET PAPER HOLDER

TRADITIONAL BUT MODERN STYLING


FOUR SCREWS INCLUDED FOR A STRONG SECURE INSTALLATION

SUPERIOR STRONG MOUNTING SYSTEM

# HARDWARE INCLUDED

- ALUMINUM TOILET PAPER ROLLER 1
- ALUMINUM WALL MOUNTING BRACKETS 2
- ZINC DIE-CAST POSTS AND FLANGES 2
- STAINLESS STEEL MOUNTING HARDWARE AND WALL ANCHORS INCLUDED

# **WALL MOUNTED**



### **INSTALLATION:**

Attach mounting bracket to wall with mounting screws. Slide flange and post over bracket and tighten set screw. Our mounting brackets are designed with horizontal and vertical adjustability to insure a proper level fit.

### **WOOD BLOCKING IS THE PREFERRED METHOD OF INSTALLATION**



THE STRONGEST MOST VERSATILE MOUNTING SYSTEM ON THE MARKET



sales@preferredbathinc.com 
www.preferredbathinc.com

(336) 904-6248



## **BENEFITS AND FEATURES**

#### **MATERIAL COMPOSITION**

SOLID STRONG ALUMINUM CONSTRUCTION

### **KEY FEATURES**

ONLY A SMALL 1/2<sup>M</sup> HOLE NEEDED TO USE THE SNAPTOGGLE® DRYWALL ANCHOR

CAN BE USED WITH MULTIPLE ANCHORS OR SCREWS TOGETHER OR SEPARATE

## VERSA MOUNTING BRACKET ™ | WOOD MOUNTED

### **METHOD ONE | ONE SCREW WOOD MOUNT**

ONE STAINLESS STEEL MOUNTING SCREW USING THE CENTER MOUNTING HOLE

### **METHOD TWO | TWO SCREW WOOD MOUNT**

TWO STAINLESS STEEL MOUNTING SCREWS USING ANY OF THE FOUR OUTSIDE MOUNTING HOLES SUPERIOR STRENGTH FOR GRAB BAR INSTALLATION





# METHOD THREE | ONE SNAPTOGGLE® DRYWALL ANCHOR

ONE SNAPTOGGLE® DRYWALL ANCHOR USING THE CENTER MOUNTING HOLE

METHOD FOUR | TWO SNAPTOGGLE® DRYWALL ANCHORS
TWO SNAPTOGGLE® DRYWALL ANCHORS USING ANY OF THE FOUR OUTSIDE MOUNTING HOLES





### METHOD FIVE | ONE SNAPTOGGLE® DRYWALL ANCHOR AND ONE SCREW WOOD MOUNT

ONE SNAPTOGGLE® DRYWALL ANCHOR CAN BE USED WITH ONE STAINLESS STEEL MOUNTING SCREW DRIVEN INTO A WALL STUD OR BLOCKING



