

NOTICE

- \* Please make sure that you have all parts indicated and they are in good condition before you begin assembly of this item. Refer to part list and hardware list below for guidance.
- \* This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- \* This item may require periodic tightening.
- \* If you are having difficulty, our friendly Customer Care team is always here to help. Please email [customersupport@safavieh.com](mailto:customersupport@safavieh.com)












PREPARATION

- \* Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- \* If any part is missing or damaged, do not attempt to assemble the product.
- \* Estimated Assembly Time: 60 minutes.
- \* Tools Required for Assembly : Allen Key (included), Phillips screwdriver (not included).

CARE AND MAINTENANCE


Adhesive felt pads should always be applied to areas of furniture which make direct contact with flooring, said application will prevent damage to the furniture and or surfaces on which the furniture lies. Objects placed on articles of furniture should rest on non abrasive material as to prevent damage to the wood finish. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish.

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	TOP PANEL		1X
B	SIDE PANEL		2X
C	DIVIDER		1X
D	SHELF		2X
E	RAIL TOP		1X
F	BOTTOM ASSEMBLY		1X
G	UPPER BACK PANEL		1X
H	LOWER BACK PANEL		1X
I	LEG		4X
J	CENTER LEG		1X
K	DOOR		4X












SAFAVIEH  
C O U T U R E

Model# SFV1310  
Product Dimensions: 69 3/4"W x 18 3/32"D x 32"H




WARNING

WEIGHT CAPACITY: 55 LBS  
WARNING: DO NOT STAND ON THE SIDEBOARD  
WARNING: DO NOT OVER TORQUE BOLTS/SCREWS


PIECE	DESCRIPTION	PICTURE	QUANTITY
HW1	BOLT 6 x 1 x 30 MM		8X
HW2	SPRING WASHER		8X
HW3	ROUND HEAD SCREW 3 x 1 x 13 MM		32X
HW4	FLAT HEAD SCREW 3 x 1 x 13 MM		16X
HW5	CAMBOLT		32X
HW6	CAMLOCK		32X
HW7	HINGE		8X
HW8	PUSH LATCH		4X
HW9	SHELF SUPPORT PIN		8X
HW10	DOWEL		12X
HW11	ALLEN KEY		1X

## PREPARATION


- \* Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- \* If any part is missing or damaged, do not attempt to assemble the product.
- \* Estimated Assembly Time: 60 minutes.
- \* Tools Required for Assembly: Allen Key (included), Phillips screwdriver (not included).
- \* If you are having difficulty, our friendly Customer Care team is always here to help. Please email [customersupport@safavieh.com](mailto:customersupport@safavieh.com)




**STEP 1** ATTACH CAMBOLTS (HW5) TO TOP PANEL (A), SIDE PANELS (B), BOTTOM ASSEMBLY (F) AND UPPER BACK PANEL (G).




**STEP 2** DETACH THE HINGE FROM THE BASE. ATTACH HINGE BASES (HW7b) TO SIDE PANELS (B) USING ROUND HEAD SCREWS 13MM (HW3). ATTACH HINGES (HW7a) TO DOORS (K) USING ROUND HEAD SCREWS 13MM (HW3).




**STEP 3** ATTACH PUSH LATCHES (HW8b) TO TOP PANEL (A) USING FLAT HEAD SCREWS 13MM (HW4). ATTACH PUSH LATCHES (HW8a) TO PUSH LATCHES (HW8b).




**STEP 4** ATTACH LOWER BACK PANEL (H) TO UPPER BACK PANEL (G) USING CAMLOCKS (HW6).




**STEP 5** ATTACH CAMBOLTS (HW5) TO UPPER AND LOWER BACK PANELS (G) AND (H).




**STEP 6** ATTACH DIVIDER (C) TO UPPER AND LOWER BACK PANELS (G) AND (H) USING CAMLOCKS (HW6).




**STEP 7** ATTACH SIDE PANEL (B) TO UNIT USING CAMLOCKS (HW6).




**STEP 8** ATTACH TOP RAIL (E) TO UNIT USING CAMLOCK (HW6).




**STEP 9** ATTACH SIDE PANEL (B) TO UNIT USING CAMLOCKS (HW6).



**STEP 10** ATTACH TOP PANEL (A) TO UNIT USING CAMLOCKS (HW6) AND DOWELS (HW10).




**STEP 11** ATTACH BOTTOM ASSEMBLY (F) TO UNIT USING CAMLOCKS (HW6) AND DOWELS (HW10).




**STEP 12** ATTACH LEGS (I) TO UNIT USING BOLTS 30MM (HW1) AND SPRING WASHERS (HW2). TIGHTEN THE BOLTS USING ALLEN KEY (HW11). ATTACH CENTER LEG (J) TO UNIT.







**STEP 13** ATTACH DOORS (K) TO UNIT.





**STEP 14** THE GAPS AND EDGES AROUND THE DOOR SHOULD BE BALANCED. IF THE GAPS ARE NOT BALANCED, PLEASE FOLLOW STEPS 15 THROUGH 17.




**STEP 15.1.** IF THE GAP ON THE TOP OR BOTTOM ARE NOT BALANCED, LOOSEN BOTH HINGE BASE SCREWS.

**BEFORE**





**AFTER**




**STEP 15.1.1.** IF THE GAP ON THE TOP IS TOO WIDE THEN SLIDE THE DOOR SLIGHTLY TO THE TOP.



**BEFORE**




**AFTER**




**STEP 15.1.2.** IF THE GAP ON THE BOTTOM IS TOO WIDE THEN SLIDE THE DOOR SLIGHTLY TO THE BOTTOM.








**STEP 15.2.** TIGHTEN BOTH HINGE BASE SCREWS.




**STEP 16.1.** IF THE EDGE ON THE LEFT OR RIGHT ARE NOT BALANCE, LOOSEN THE BACK CENTER SCREW.




**STEP 16.1.1.** IF THE EDGE ON THE LEFT SIDE IS TOO WIDE, YOU WILL NEED TO SLIDE THE DOOR SLIGHTLY TO THE LEFT BY TURNING THE FRONT CENTER SCREW COUNTER CLOCKWISE.




**STEP 16.1.2.** IF THE EDGE ON THE LEFT SIDE IS TOO NARROW, YOU WILL NEED TO SLIDE THE DOOR SLIGHTLY TO THE RIGHT BY TURNING THE FRONT CENTER SCREW CLOCKWISE.




**STEP 16.2.** TIGHTEN THE BACK CENTER SCREW.




**STEP 17.1.** IF YOU NEED TO SLIDE THE DOOR FORWARD OR BACKWARD, PLEASE FOLLOW THIS STEP.




**STEP 17.2.** LOOSEN THE BACK CENTER SCREW.




**STEP 17.2.1.** IF YOU NEED TO SLIDE THE DOOR BACKWARD, PUSH THE DOOR SLIGHTLY.




**STEP 17.2.2.** IF YOU NEED TO SLIDE THE DOOR FORWARD, PULL THE DOOR SLIGHTLY.




**STEP 17.3.** TIGHTEN THE BACK CENTER SCREW.




**STEP 18** INSERT SHELF SUPPORT PINS (HW9) INTO LEFT PANEL AT DESIRED LEVEL.




**STEP 19** PLACE THE LEFT SIDE OF THE SHELF PANEL (C) INTO POSITION.



**STEP 20** HOLDING IT ON THE RIGHT SIDE OF THE SIDE PANEL HIGHER THAN THE DESIRED LEVEL, INSERT THE REST SHELF SUPPORT PINS (HW9) INTO RIGHT PANEL AT DESIRED LEVEL.



**STEP 21** PLACE THE RIGHT SIDE OF THE SHELF PANEL (C) INTO POSITION.



**STEP 22** ADJUST THE ADJUSTER THAT HAS ALREADY BEEN ASSEMBLED TO THE LEGS TO STABILIZE YOUR UNIT.