

# JONATHAN ADLER

## LIGHTING

### Caracas 16-Light Chandelier (UL Version)

#### Assembly Instructions

**NET WEIGHT OF THIS FIXTURE: 28 LBS**

#### Safety Instruction:


- These instructions are provided for your safety, it is important that they are read carefully and completely before assembling.
- PLEASE SAVE THESE INSTRUCTIONS
- We strongly recommend that a professional electrician install all direct wire fixtures.
- The lighting fixture is meant for indoor use, DRY LOCATIONS ONLY.
- To reduce the risk of fire, electrical shock or personal injury, always turn off light fixture and allow it to cool prior to replacing light bulb.
- Do not touch bulb when fixture is turned on. Do not look directly at light bulb. Keep flammable materials away from light bulb.
- This fixture takes (16) 25 Watt MAX Type B Candelabra Bulb (not included).

#### Pre-assembly:

- Remove all parts and hardware from box along with any plastic protective packaging and carefully lay all the parts out on a clean, flat surface.
- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.

#### ASSEMBLY INSTRUCTIONS:

1. SHUT OFF MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER. IT IS RECOMMENDED THAT A LICENSED ELECTRICIAN INSTALLS THIS FIXTURE.
2. Screw all KD parts or according to desired height of light, assemble the needed Stem by screwing KD together tightly.
3. Insert (16) 25 Watt MAX Type B Candelabra Bulb (not included) (C) into



the socket (G).

4. Insert the lamp shade gap into the lamp cup (K), and screw shade tighten by hand with clockwise rotation.
5. Cut three prong plugs from the end of the electrical cord.
6. Fixture the mounting plate (A) on the junction box (M) by using screw (D).
7. From the back side of canopy (B), pull the electrical cord up through nipple (E).
8. Cut the cord to the desired length for making electrical connection.

At least six inches of wire will be needed to make proper electrical connection.

9. Carefully unscrew nipple (E) from canopy (B).

Thread plug (F) into hole vacated by the electrical cord and nipple (E).

10. Carefully pull the wiring from wall junction box.

Thread the wires through the center hole in mounting plate (A).

11. Connect ground (green or silver in color) wire from fixture to ground wire in the junction box.

Fasten wires together with wire nut and tightly wrap the connection with electrical tape.

12. Attach hot wire from fixture (black in color or smooth side of wire) to hot wire from outlet box.

Fasten wires together with wire nut and tightly wrap connection with electrical tape.

13. Attach neutral wire from fixture (white in color or ribbed side of wire) to neutral wire from outlet box.

Fasten wires together with wire nut and tightly wrap connection with electrical tape.

14. Slide canopy (B) over mounting plate (A).

Thread screws (D) into vacant holes at the top and sides of canopy (B) to secure the fixture to the mounting surface.

15. Reconnect main electrical supply from the fuse box/circuit breaker and test fixture.

16. Assembly is completed.

## Care Instruction:

- Wipe clean using a soft, dry cloth or static duster.
- Always avoid the use of harsh chemicals and abrasives to clean fixture as they may damage the finish.