




Item # : W40FPXFJ  
Assembly Instructions




*Please visit our website for the most current instructions, assembly tips, report damage, or request parts. [www.walkerredison.com](http://www.walkerredison.com)*


Revised 04/25/2018

# General Assembly Guidelines














- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The main type of hardware used to assemble this product is: bolts.
- V. Power tools should not be used to assemble this product .




# Parts List



# Hardware List


A		Ø1/4"x25mm	Bolt	20 pcs
B		Ø1/4"x12mm	Bolt	30 pcs
C		Ø4x25mm	Screw	4 pcs
D			Bracket	2 pcs
E		Ø1/4"x25mm	Bolt	4 pcs
F		Ø4x38mm	Screw	4 pcs
G		M4	Hex Key	1 pcs
H		Ø4x12mm	Screw	4 pcs
J			Bracket	2 pcs
K		Ø16	Washer	2 pcs
L		Ø4x30mm	Screw	2 pcs
M			Anchor	2 pcs
N			Foam Pad	2 pcs



Philips head screwdriver required for assembly  
(not included)


*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

## Step 1




Attach part (10,16) to part (1) using bolt (B) and Hex Key (G).

## Step 2




Attach part (13) to part (3) using bolt (B) and Hex Key (G).

## Step 3




Attach part (11,12) to part (2) using bolt (B) and Hex Key (G).

## Step 4




Attach part (9) to part (4) using bolt (B) and Hex Key (G).

## Step 5




Attach part (8) to part (5) using bolt (B) and Hex Key (G).

## Step 6




Attach part (14) to part (6) using bolt (B) and Hex Key (G). Complete this step twice.

## Step 7



Attach part (14) to part (8) using bolt (E) and Hex Key (G).


## Step 8



Attach part (14) to part (9) using bolt (E) and Hex Key (G).




## Step 9




Attach part (9) to part (11,12) using bolt (A) and Hex Key (G). Attach part (12) to part (9) using screw (C) and a screwdriver.

## Step 10




Attach part (8) to part (11, 12) with bolt (A) and Hex Key (G). Attach part (12) to part (8) using screw (C) and a screwdriver. Place Foam Pad (N) on part (8, 9) as per diagram.

## Step 11




Attach part (13) to part (8,9) using bolt (A) and Hex Key (G).

## Step 12




Secure part (3) to part (4,5) using screw (F) and a screwdriver.

## Step 13




Attach part (7) to part (10,13,14,16) using bolt (A) and Hex Key (G).

## Step 14




Attach part (7) to part (10,13,14,16) using bolt (A) and Hex Key (G).

## Step 15




Place fireplace (15) into the frame from the rear.

## Step 16




Secure the fireplace (15) to the frame part (4) using bracket (D) and screw (H).

## Step 17





Secure the fireplace (15) to the frame part (5) using bracket (D) and screw (H).

## Step 18



Attach bracket (J) to back frame part (16) using bolt (B) with hex key (G).

## Step 19





Wall

Measure height for bracket in desired location. Insert anchor (M) into wall at desired location.


## Step 20

Wall



Secure furniture to anchor (M) in wall through bracket (J) using washer (K) and screw (L) with a screwdriver.

## Step 21



Final Assembly