




USER MANUAL

NE



BATHROOM
SMART MIRROR

Package Including

Components may differ in different locations.

Contact the vendor where you purchased the product if any components are missing. The appearance of the components may differ from the images shown.



Smart Mirror



Beauty fatscale *1
(optional)




Skin Tester *1
(optional)



Bracket 2 sets




Screw *4



Power wire



Expansion screw*4



INSTALLATION

Bathroom Protection Areas

For installations in wet-rooms, such as bathrooms, specific installation guidelines apply. These regulations differ by region. Please contact a specialist for this. Therefore electrical installations are to be performed by a skilled technician.





This product is subject to protection class IP65. This protects the product against splashing water from any angle.


Product installation

1. Close the concave surface of wall hanger to the wall


2. Adjust the wall hanging bracket to a proper position. After adjustment, stick the wall hanging bracket to the wall. Use a pencil to make a hole mark in the mounting hole of the wall bracket.




3. Use an electric drill to drill 5/16 (in) diameter holes in the marked wall, tap in anchor bolts and lock the wall hanger with screws.



Drill hole




Tap anchor




Lock wall hanger


4. Make the mirror hanged on the wall hanger and the two magnet buttons make the mirror and hanger clung together



5. Connect 110-220V power supply. The logo button will turn blue after power supply connecting



STEP 1:

Long press “  ” for 3 seconds until the logo button turn white. (Long press 3 seconds again will turn off the mirror.)




STEP 2:


Touch the START button



Time
Date
Weather





STEP 3: SETTING



- WI-FI: connect wifi
- Bluetooth: connect bluetooth
- Sleep: turn off and the mirror will be stay sleep, when u close to, it will be wake up.
- Temp: select °F or °C
- Time: adjust time to match your local time
- Language: choose the language
- Lighting: adjust the led lighting and color
- Clean: clean the system garbage
- About: system detail(when report after service, pls provide this system detail page)

STEP4:How to quit when u open one function, there are two ways

1. If the page shows “  ”then just touch the button
2. If the page show no back to home icon, then pls follow below steps
Pull down from the bottom line until there shows below:



STEP5:

How to use body fat scale

Touch health function button and stand on the body fat scale

How to use skin tester


Press the skin tester bottom button when it turns green, Touch the health function button, select skin tester function, press the skin tester to your face.



User Portal

www.vtouchscreen.com

There you can:









The list of applications can be changed or adjusted by us at any time without prior notice. It is therefore useful to visit the portal from time to time to use new applications.



When you make changes in the portal, it takes about 30 seconds to activate them and appear on your devices





Touch the Brand button with 8s to start or shutdown the smart mirror



S40



S50



Software and CPU Configuration

Main Frequency	Quad Core Cortex A17 1.8GHZ
GPU	Mali-T764
RAM	2GB
Flash Memory	8 GB
Wifi	2.4GHz+5.0GHz dual-band WiFi 802.11a/b/g/n
Bluetooth	4.0
Operating System	Android 5.1.
Capacitive Touch Screen	10 touch points
Power Switch	Touch
Human Body Sensor	0~50cm
ZigBee Module	Optional

Mirror Screen with Capacitive Touch

Touch Display Screen	21.5" IPS
Zoom	16:9
Resolution	1920 x1080
Brightness	250cd/m ²
Contrast	3000:1 (by screen specifications)
Viewing angle	89°/89°/89°/89°
Response time	13/5 (Typ.)(Tr/Td) ms
Mirror transmittance	35%
Anti-fingerprint coating on mirror	Yes
Life Span	≥25000 Hour

I/O

USB	USB-typeC*1
-----	-------------

Speaker

AUDIO OUT	8 Ω 5w*2
-----------	----------

Working/Storage Environment

Working/storage humidity	20% to 80 % RH, No Condensation
Working/storage temp.	0 to 60 °C /-20 to 80 °C

Power/power consumption

Power Input (built-in switching power supply)	AC 100-240V 50/60Hz
Power Consumption	≤60W
Standby Power Consumption	≤0.5W

Installation Method

Wall Mounted Installation

Appearance / Materials / Crafts

Certificate	CE/FCC/CCC/ISO9001
Panel Glass	dielectric mirror
Material / Process	Stainless steel hanger, aluminum alloy frame, plastic sound cavity, etc.
Dustproof and Waterproof	IP65

Warranty

v.

AQUADOM warrants to the original purchaser that it will, at its election, repair, replace, or make appropriate adjustment to products made by this company shown to have significant defects in material or workmanship which are reported to AQUADOM in writing within one (1) year from the date of delivery. AQUADOM is not responsible for installation costs.

The warranty is void in the event the product is damaged in transit, or if damage or failure is caused by abuse, misuse, abnormal usage, faulty installation, damage in an accident, improper maintenance, or any repairs other than those authorized by AQUADOM.

At the expiration of the one-year warranty period, AQUADOM shall be under no further obligation under any warranty, expressed or implied, including the implied warranty of merchantability.

AQUADOM shall not be liable for any consequential damages arising out of or in connection with the use or performance of its products. Some states do not allow limitations on how long an implied warranty lasts or do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Any liability against AQUADOM under any implied warranty, including the warranty of merchantability, is expressly limited to the terms of this warranty. Permission to return any merchandise under this warranty must be authorized by AQUADOM and returned prepaid by the purchaser.



ABOUT THIS MANUAL

About this manual

Please read the corresponding instructions of this manual prior to the first usage of the device, even if the usage of electronic devices is familiar to you. Notice especially the chapter SAFETY PRECAUTIONS.

Please do keep this manual in a safe place for future references.

When selling the device or giving it away, absolutely give these directions for use.



An administration fee may be charged if either

- an engineer is called out at your request and there is no defect in the product (i.e. where you have failed to read this user manual)
- you bring the unit to a repair centre and there is no defect in the product (i.e. where you have failed to read this user manual)

The amount of such administration charge will be advised to you before any work or home visit is carried out.

Symbols



WARNING

A serious or fatal injury may result if instructions are not followed.



CAUTION

Injury or damage to property may result if instructions are not followed.



NOTE

Instructions followed by this symbol must be followed.



1. Never remove the housing covers or modify the product in any way. This can cause an electric shock or burn you.
2. Do not overload wall outlets, extension cords or adaptors above their capacity, since this can result in fire or electric shock.
3. Immediately cut power, if you notice that your product emits smoke, smells burnt or emits unusual noises and ask your specialist dealer for advice.
4. Do not allow the product to come into direct contact with liquids. Liquid in the housing can cause a fire, electric shock or damage the device. Immediately cut the power, if an item or liquid gets into the housing.
5. Only qualified specialist staff may carry out service tasks. Service work is necessary, if the unit has been damaged, e.g. if the mains plug or mains cable have been damaged, if liquid or items are present inside the device, if it has been exposed to rain, if it does not work properly or if it has fallen down.
6. Never touch uninsulated parts of the plug, if the device is connected to the power supply!
7. The device may only be operated with the provided power pack. The rated voltage is 100 – 240V ~ 50Hz. Use only cables suitable for your local power supply. Install the mains cable in such a way that it does not obstruct anyone. Ensure furthermore that the cable is not clamped, in particular at the plug, at the female connectors and where it exits the device. Do not install the mains cable in the proximity of heating elements and never place heavy items on the cable. Do not modify or arbitrarily repair the mains cable.
8. Do not use any power cords or adaptors other than those provided with this product! Use of power cords or adaptors other than those provided with this product may cause fire, electric shock or malfunction.
9. The device is rated to be connected to a mains with rating max. 16A. The electrical installation need to be protected with 30 mA.
10. Never cut or damage the power cord!
11. Please disconnect the device from the power supply in the following cases:
 - The device is out of use for a lengthy period.
 - The device malfunctions or displays other unusual features, necessitating maintenance work.
 - During a thunderstorm or lightning.
12. Do not use multiple products with a single power socket.

CAUTION

RISK OF ELECTRIC SHOCK – DO NOT OPEN

Caution: to reduce the risk of electric shock, do not remove cover (or back). There are no user serviceable parts inside. Refer all servicing to qualified personnel.

SAFETY PRECAUTIONS



Installation

1. Avoid direct sun exposure, direct proximity to heat sources, outdoor installation or storing in a car. The product is specifically designed for indoor use only. There is the danger of fire and of electric shocks and damage to the device, if it is operated outdoors.
2. Do not place candles, insect repellants or cigarettes on top of the product. Do not install the product near to heat sources.
3. Keep the plastic packaging out of reach of children, children may suffocate.
4. Keep out of reach of children. Failure to observe this precaution could result in injury.
5. Edible oil, such as soybean oil, can damage or deform the product. Do not install the product in a kitchen or near a kitchen counter.
6. Do not drop the product while moving.
7. Do not set down the product on its front (glass side) or corners.
8. Set down the product gently.
9. Structural measures must be accomplished for an on-wall installation. We decline any liability for the screws and screw anchors used on site.
10. The product is engineered vertical use only. Verify walls verticality and items vertical and horizontal alignment to prevent serious injuries and product damage.
11. Do not install the product alone on yourself. Two persons are required to perform a safe installation.
12. The corners and edges of the glass are very delicate. Take care that they do not hit the wall, ceiling or floor in any way to avoid damages and split-offs.
13. The surface of the glass is very sensitive. Do not use a cutter or knife to remove the protective foil in order to avoid scratches and other damages.
14. The product is delivered with a protective film covering the glass in order to avoid scratches and damages. Only remove the protective film once the product is installed and hanging safely on the wall.
15. Installing the product in an unusual place (a place exposed to a lot of fine dust, chemical substances, extreme temperatures or a significant presence of moisture, or a place where the product will operate continuously for an extended period of time) may seriously affect its performance and lifetime.
16. Parts of this product are made out of glass. Handle with care to avoid injury or damage. Always wear safety shoes and gloves when handling the products or its packaging.



17. There are numerous types of wall and structures, that's why we can not provide the fittings, screws and anchors for your wall. First determine the type of wall to which you want to attach the product in order to buy the appropriate fittings, screws and anchors.

18. Mounting this product requires structural measures and special skills. Refer exclusively to qualified personnel. Electrical connections must be performed by qualified professionals expecting national regulations and standards.

19. For installations in wet-rooms, such as bathrooms, specific installation guidelines apply. These regulations differ by region. Please contact a specialist for this. Therefore electrical installations are to be performed by a skilled technician, while observing the regulations of the standard DIN VDE 0100 T.701.

20. This product includes heavy, bulky and delicate items. To prevent damages to your product or injury to yourself or to others, prepare the installation environment properly. Clean the handling and installation environments properly before installation. Before installation cushion the floor properly using soft anti slip mats near the handling areas. Lay the items gently on these cushioned anti slip surfaces when needed.



Operation

1. There is a high voltage inside the product. Never disassemble, repair or modify the product yourself.
2. Before moving the product, disconnect the power cable.
3. If the product is dropped or the outer case is damaged, disconnect the power cord. Then contact the service center.
4. Do not drop objects on the product or apply impact.
5. If a gas leakage is found, do not touch the product or power connection. Also, ventilate the area immediately.
6. Do not use or keep combustible spray or an inflammable substance near the product.
7. Do not insert metallic objects (chopsticks, coins, hairpins, etc) or objects that burn easily (paper, matches, etc) into the product.
8. Do not place objects containing liquid (vases, pots, bottles, etc) or metallic objects on top of the product.
9. Leaving the screen fixed on a stationary image for an extended period of time may cause afterimage burn-in or defective pixels.
10. Do not hold the product upside-down.
11. Do not use humidifiers or stoves around the product.
12. Store small accessories out of the reach of children.

SAFETY PRECAUTIONS

13. Do not place heavy objects (e.g. decor frames) on the product.
14. Be careful that children do not place the battery in their mouths when removed from the remote control. Place the battery in a location that children or infants cannot reach.
15. If children have had the battery in their mouths, consult your doctor immediately
16. When replacing the battery, insert it with the right polarity (+/-).
17. Use only the specified standardized batteries, and do not use a new battery and a used battery at the same time.
18. The batteries are not ordinary refuse and must be returned for recycling purposes. You are responsible for returning the used batteries for recycling. You can return used batteries to a nearby public recycling centre or to a store selling the same type of the battery.
19. Trouble free operation is ensured up to 80% air humidity. To prevent fire or electric shock, never allow liquids to enter the unit.
20. The ambient temperature for operating the device is between +5 and +40 degrees Celsius. Do not install the device in the proximity of heat sources, such as heating pipes, heaters, furnaces or other devices, which radiate heat. It is not absolutely necessary to provide air circulation to dissipate the heat.
21. All maintenance and/or service tasks, as well as repairs may only be carried out by trained customer service personnel.
22. Never let children use electrical devices unsupervised. Children can't always recognize properly the possible dangers.
23. This appliance is intended solely for private domestic use and may not be used for industrial and commercial purposes. We exclude liability in principle if the device is not used as intended, or unauthorized modifications have been made.
24. Packaging and packaging aids are recyclable and should principally be recycled. Packaging materials such as foil bag and cover foil must be kept away from children.



Operation

The product must be stored in dry and well-ventilated rooms, without extreme temperature fluctuations. Heat sources and aggressive active substances may not be stored in the proximity of the device. The required storage temperature is 0° C – +60° C at an air humidity of 5 – 85% RH. The device must be stored in the complete packaging, as delivered.



Home network and Wi-Fi requirements for bathroom application

Overview:

Bathrooms are usually enclosed by walls which cause attenuation. Rooms, on the other hand, have windows which allow cellular/Wi-Fi signal to enter and propagate more easily.

Bathrooms might have metal sheet on the door to prevent its wood from getting soaked. This reflects away most of the RF signal.

There is a network of pipes which impedes signal and creates multi-path

Water (and moisture) absorbs radio signal at higher frequencies. This is why microwave ovens operate at ~2.4GHz, which incidentally is the same as WiFi

Minimum Requirements:

You will need a high-speed DSL/Cable modem, or fiber-to-the-home broadband connection for proper playback of Internet-based music and video services.

If your Internet service provider only offers Satellite Internet access, you may experience playback issues due to fluctuating download rates.

In order to take advantage of Smart Mirror's automatic online updates, or stream music and video from an Internet-based content provider, you must install a wireless router in your home network. If you do not have a wireless router, purchase and install one before proceeding

Please make sure your router, modem and/or wireless network specifications meet the followings:

Wireless Network Specifications: Open, WEP, WPA-PSK or WPA2-PSK encryption. Wireless Router/Modem Specifications: B,G or N routers on 2.4GHz

Connect a Wi-Fi Range Extender to your Wi-Fi system if:

- You have a larger home where the WiFi performance isn't reliable and you want to strengthen the wireless reception in your bathroom for your Smart Mirror.
- Your WiFi network is already in high demand with streaming video and web surfing and you want to create a separate wireless network exclusively for your Smart Mirror.

Helpful hints once experiencing "buffering" on streaming content.

- Try to move your Wireless Access Point away from physical objects that can block your Wi-Fi signal - especially enclosed cabinets.
- Restart your network device (router, wap, extender etc.)
- Analyze which channel your Wi-Fi is using. You can do this with help Wi-Fi Analyzer app available in play store. Change your router setting in such a way that your channel is different from your neighbors Wi-Fi. The app itself shows recommendations for the channel.

SAFETY PRECAUTIONS



Cleaning and Product Care

1. Use a soft damp cloth (cotton, flannel, etc.) and gently wipe the surface of the product. Wiping with a hard cloth or using strong force may scratch the surface of the product. Never touch, push, rub or strike the screen with any object.
2. Avoid using benzene, thinner and other solvents as they may deform the product and may cause the paint to peel off or damage the surface. Using a chemical cloth (wet/dry sheet type cloth, etc.) may cause damages and corrode the product. To avoid deformation, corrosion and color fading, wipe off water drops as soon as possible.
3. The following items may never be used for cleaning: solvents, cleaning petrol, scrubbing milk, spray cleaner, wax, acids, caustic solutions or the like. These agents may cause damages and corrode the product.