

**GEOHOME®**

*ART WITH AN ATTITUDE*




## **Assembly Instruction**

**GEOHOME**  
Cat Little Box


MODEL : **I601-40 / I601-41**

DIMENSION : 91 cm(W) x 52 cm(D) x 43.4 cm(H)

### TOOL REQUIRED



# EXPLODED VIEW




## IMPORTANT NOTE:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Do not tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children.

# PARTS LIST


**A**



TOP PANEL

1 PC


**B**



BOTTOM PANEL

1 PC


**C**



SIDE PANEL

2 PCS


**D**



BACK PANEL

1 PC


**E**



CENTER PANEL

1 PC


**F**



LEFT DOOR PANEL

1 PC

**G**




RIGHT DOOR PANEL

1 PC


# HARDWARE LIST

1




CAM-LOCK SCREW    6 PCS

2




CAM-LOCK NUT    6 PCS

3




SCREW    6 PCS

4




WOOD DOWEL    14 PCS

5




DOOR SPRING    4 PCS

6




MAGNET    2 PCS

7




FLAT SCREW    2 PCS

8



NAIL LEG    6 PCS


A



TOP PANEL


1 PC

1

CAM-LOCK  
SCREW

6 PCS


6




MAGNET

2 PCS


## STEP 1



TOOL REQUIRED




C



SIDE PANEL

2 PCS

E



CENTER PANEL

1 PC


2



CAM-LOCK NUT

5 PCS


4



WOOD DOWEL


10 PCS

## STEP 2



ARROW FACING OUTWARD


D



BACK PANEL

1 PC


2



CAM-LOCK NUT

1 PC


4



WOOD DOWEL


4 PCS

## STEP 3



ARROW FACING OUTWARD


A



TOP PANEL

1 PC


C



SIDE PANEL

2 PCS


D



BACK PANEL

1 PC


E




CENTER PANEL

1 PC


## STEP 4




TURN 180°




TOOL REQUIRED






ASSEMBLED UNIT




BOTTOM PANEL 1 PC





SCREW 6 PCS


## STEP 5



TOOL REQUIRED




ASSEMBLED UNIT




NAIL LEG 6 PCS


## STEP 6



TOOL REQUIRED




F




LEFT DOOR PANEL 1 PC

G




RIGHT DOOR PANEL 1 PC

5




DOOR SPRING 4 PCS

7





FLAT SCREW 2 PCS

## STEP 7




TOOL REQUIRED




ASSEMBLED UNIT

## STEP 8







## STEP 9




ASSEMBLED UNIT




LEFT DOOR PANEL 1 PC



RIGHT DOOR PANEL 1 PC



## Recommended Maximum Weight



### **WARNING:**

>This unit has been designed to support the maximum loads shown. Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.

>DO NOT allow children to climb on unit.

> Put heavier items on lower shelves.