


Assembly Instructions



Bathroom Rack



NOTE TO CUSTOMERS:

- For ease and speed of assembly we recommend that before you commence each step of the assembly that you identify all the parts required to complete that step.
- We recommend that where possible you allow sufficient space to assemble the item as close as possible to the place where it will be once assembled.
- For the protection of your furniture we recommend that the product is placed on protected surfaces during assembly to prevent any damage.
- During assembly do not over tighten, as this may damage the product.
- Please ensure you retain all the product packaging until the item completely assembled.
- Please periodically check all fittings and re-tighten as necessary.
- Never allow any liquids to remain on your furniture as absorption can cause the wood to warp or the finish to de-laminate.
- It is recommended that this item should be assembled by two adults.

To use a cam lock: (Please read below instructions before assembling)



1. Insert cam screw into hole as shown in diagram A .





Diagram B

Make sure not to insert the cam screw:
Too deep as shown in figure B as this will cause the
cam screw to be misaligned and unable to
interlock properly.







Diagram C


Also avoid inserting the cam screw too close to the
surface of the hole as shown in figure C, as this will
cause the cam lock to be too loose, and not interlock
properly.



2. Connect the panels together.



3. When inserting the cam lock make sure the arrow
of the cam lock faces the cam screw.
















4. To tighten the cam lock turn the cam lock clockwise
90-180 degree or until the arrow is facing opposite
the place cam lock was inserted.

NOTE: DO NOT USE AN AUTOMATIC
SCREWDRIVER TO TIGHTEN CAM LOCKS.














Note:

- Read these instructions carefully before assembling.
- Tools required : Phillips screwdriver, flat screwdriver.
- Find a clean, smooth area on which to work , such as a carpet, in order to avoid scratching the wood surfaces.
- Wait to dispose of the packing material until assembly is complete and all parts and hardware are accounted for.
- Two or more people might be required for assembly.








Part List

PART	FIGURE	DESCRIPTION	QTY	PART	FIGURE	DESCRIPTION	QTY
A		TOP PANEL	1PC	H		ADJUSTABLE SHELF	1PC
B		BOTTOM PANEL	1PC	I		LEFT DOOR	1PC
C		UPPER LEFT SIDE PANEL	1PC	J		RIGHT DOOR	1PC
D		UPPER RIGHT SIDE PANEL	1PC	K		UPPER RAIL	2PCS
E		LOWER LEFT SIDE FRAME	1PC	L		LOWER RAIL	1PC
F		LOWER RIGHT SIDE FRAME	1PC	M		BACK PANEL	1PC
G		MIDDLE SHELF	1PC				

HARDWARE LIST

PART	FIGURE	DESCRIPTION	QTY	PART	FIGURE	DESCRIPTION	QTY
1		CAM LOCK	8PCS	8		BOLT	2PCS
2		CAM BOLT	8PCS	9		SHELF SUPPORT	4PCS
3		WOOD DOWEL	16PCS	10		SCREW	16PCS
4		MAGNET	1PC	11		SCREW	10PCS
5		HINGES	4PCS	12		BOLT	4PCS
6		SCREW	16PCS	13		ANCHOR	2PCS
7		KNOB	2PCS				

APPENDIX: Dimension of Hardwares in this AI.


<p>(1)&(2).</p>  <p>Cambolt & Camlock</p>	<p>(3).</p>  <p>Wood Dowel</p>	<p>(6).</p>  <p>Screw</p>
<p>(8).</p>  <p>Bolt</p>	<p>(10).</p>  <p>Screw</p>	<p>(11).</p>  <p>Screw</p>
<p>(12).</p>  <p>Bolt</p>		

1



2 PCS

2




4 PCS

3




8 PCS

4




1 PC

5




4 PCS

6






8 PCS

10




2 PCS

STEP 1



- 1). Attach Magnet (4) to Top Panel (A) using Screws (10).
 - 2). Screw and insert Cam-bolts (2) & Wood Dowels (3) to Top Panel (A).
 - 3). Attach Hinges (5) to Doors (I)&(J) using Screws (6).
- Note: Holes are pre-drilled for Screws (6)&(10).

STEP 2



Assemble Upper Side Panels (C)&(D) to Middle Shelf (G) using Camlocks (1), Cam-bolts (2) and Wood Dowels (3).

1



2 PCS

3




2 PCS

11




4 PCS

STEP 3



Assemble Top Panel (A) to Upper Side Panels (C)&(D) using Camlocks (1).

STEP 4



Assemble Bottom Panel (B) to Upper Side Panels (C)&(D) using Wood Dowels (3) and Screws (11).

Note: Holes are pre-drilled for Screws (11).

1



4 PCS

2




4 PCS

3




4 PCS

10




14 PCS

STEP 5



Assemble Back Panel (M) to the back of this unit using Screws (10).
Note: Holes are pre-drilled for Screws (10).

STEP 6




Assemble Lower Side Frames (E)&(F) to Upper Rails (K) using Camlocks (1),
Cam-bolts (2) and Wood Dowels (3).

3




2 PCS

11




4 PCS

12




4 PCS

STEP 7



Assemble Lower Rail (L) to Lower Side Frames (E)&(F) using Screws (11).
Note: Holes are pre-drilled for Screws (11).

STEP 8




Assemble Lower Side Frames (E)&(F) to Bottom Panel (B) using Wood Dowels (3) and Bolts (12).

6



8 PCS

7



2 PCS

8




2 PCS

9



4 PCS


STEP 9



- 1). Assemble Doors (I)&(J) to Upper Side Panels (C)&(D) using Screws (6).
 - 2). Attach Knobs (7) to Doors (I)&(J) using Bolts (8).
- Note: Holes are pre-drilled for Screws (6).

STEP 10

Insert Shelf Supports (9) into the holes of Upper Side Panels (C)&(D), then put Adjustable Shelf (H) onto Shelf Supports (9).




11




2 PCS

13



2 PCS

STEP 11



For your safety, please attach this unit to the wall by Screws (11) and Anchors (13).