




MOUNTING INSTRUCTIONS

Sit and Stand Desktop



Features & Specifications



A
LB
kg 28.6lbs
(13kg)

B
LB
kg ≤5lbs
(≤2kg)


LB
kg
A+B= 28.6 lbs (13 kg)

**CAUTION: DO NOT EXCEED
MAXIMUM LISTED WEIGHT
CAPACITY. SERIOUS INJURY
OR PROPERTY DAMAGE MAY
OCCUR!**



Components

	A	B	C	D	E
1					
		X1	X1	X6	X2


Tools required not included



1






When carrying the lift table, be sure to hold the bottom with both hands. Do not subject the table to a separate force. This can cause the tabletop to be out of step with the bottom structure.




**Warning: Impact Hazard! Moving
Parts can Crush and Cut.**


2




3



6




4




7




! Keep monitor and laptop base fully on the worksurface. Allowing any part of base or stand to hang off the edge may result in property damage and or personal injury.



! Raise worksurface slowly. Raising worksurface too fast may create an unstable situation resulting in property damage and or personal injury.





! Leave enough slack in cable to allow for full range of vertical motion (15" / 38 cm). Failure to heed this warning may result in property damage and or personal injury.



! To avoid the potential to pinch cables it is important to follow the cable routing instructions in this manual. Failure to follow these instructions may result in equipment damage or personal injury.

5



! WARNING

PINCH POINT

DO NOT place hands on or near support bars. Pinch points are created during lifting and lowering the worksurface. Failure to follow these instructions may result in serious personal injury.

