

## INSTALLATION INSTRUCTIONS **Features**

## Oil rubbed bronze finish

- Kerox™ Ceramic Disc Cartridge
- Solid brass construction
- · Pull-out spray head with multi-function feature
- Up to 2" deck thickness
- 1 hole installation(standard 1-3/8" hole)
- Certified and listed by cUPC to meet Industry Codes and Standards for USA & Canada



This product complies with the new federal "lead-free" requirement of the 2014 Reduction of Lead in Drinking Water Act, as well




as state legislations in California (AB-1953) and Vermont (S-152).

- Spout Reach: 8 75"
- **Dimensions** Overal Height: 18.25" Spout Height: 9.25"



Spray Kitchen Faucet



## shank (Figure 1). If you look closely, you will find a black rubber O ring

the base of the faucet, just above the threaded shank. Do not remove this O ring (Figure 1). 2. Attach the hot and cold water sup-

ply hoses to the faucet by screwing the male end of each hose into the base of the faucet body (Figure 2).

1. Remove rubber washer, metal

washer, and locknut from the threaded

sitting in a groove on the underside of




Figure 2

3. Place the faucet body into the faucet hole of the deck/sink (Figure 3). A standard 1-3/8" hole is required

for this faucet.

4. From underneath the deck/sink, slide the rubber washer followed by the metal washer all the way up the threaded shank of the faucet (Figure 5. Screw the locknut all the way up

the threaded shank of the faucet until tight. Then using a Phillips- Head Screwdriver, tighten the screws of the locknut until tight (Figure 4).

weight until it is in two pieces. Place one half of the hose weight on the center sections of the spray hose. Then place the remaining half of the weight against the other half and reinsert the screws. Do not tighten the

screws completely yet (Figure 5).

6. Unscrew both screws of the hose





Figure 4

**7.** Connect the spray hose by screwing it into the spray hose pipe (Figure 6). 8. Make sure the spray hose weight is vertical on the loosest section of the

spray hose and tighten the screws with a Phillips-head Screwdriver to

secure it into place.



10. Then screw the remaining female ends of the supply hoses to the corresponding hot and cold water supply using an adjustable wrench

11. Turn water supply on (Figure 8). Test the faucet by turning it on and off. Make sure there is good water flow and no leaks. Inspect the faucet above and below the countertop to make sure there are no leaks. If there is a leak, turn the water supply off and contact Ruvati Support.

or pliers (Figure 8).







Figure 6







This General diagram and installation instructions are not intended for any specific model, but is presented as a general guideline for Installations!