



ASSEMBLY INSTRUCTIONS




NOTE TO CUSTOMERS:

- For ease and speed of assembly we recommend that before you commence each step of the assembly that you identify all the parts required to complete that step.
- We recommend that where possible you allow sufficient space to assemble the item as close as possible to the place where it will be once assembled.
- For the protection of your furniture we recommend that the product is placed on protected surfaces during assembly to prevent any damage.
- During assembly do not over tighten, as this may damage the product.
- Please ensure you retain all the product packaging until the item completely assembled.
- Please periodically check all fittings and re-tighten as necessary.
- Please never allow any liquids to remain on your furniture as absorption can cause the wood to warp or finish to de-laminate.
- It is recommended that this item should be assembled by two adults.


To insert a cam lock: (Please read below instructions before assembling)




1. Insert cam screw into hole as shown in diagram A .




Make sure not to insert the cam screw:
Too deep as shown in figure B as this will cause the cam screw to be misaligned and unable to interlock properly.




Also avoid inserting the cam screw too close to the surface of the hole as shown in figure C, as this will cause the cam lock to be too loose, and not interlock properly.



2. Connect the panels together.



3. When inserting the cam lock make sure the arrow of the cam lock faces the cam screw.




4. To tighten the cam lock turn the cam lock clockwise 90-180 degree or until the arrow is facing opposite the place cam lock was inserted.

NOTE: DO NOT USE AN AUTOMATIC SCREWDRIVER TO TIGHTEN CAM LOCKS.


Note:

- Read these instructions carefully before assembling.
- Tools required : Phillips screwdriver, flat screwdriver.
- Find a clean, smooth area on which to work , such as a carpet, in order to avoid scratching the wood surfaces.
- Wait to dispose of the packing material until assembly is complete and all parts and hardware are accounted for.
- Two or more people might be required for assembly.


Part List




A1: Top Panel 1pc




A2: Left Side Panel 1pc




A3: Right Side Panel 1pc




A4: Bottom Panel 1pc




A5: Shelf 1pc




A6: Divider 2pcs




A7: Apron 2pcs




A8: Drawer Front Panel 3pcs




A9: Drawer Side Panel 6pcs



A10: Drawer Back Panel 3pcs











A11: Drawer Bottom Panel 3pcs




A12: Back Panel 1pc

Hardware List

| | | |
|--|--|--|
|  <p>B1 : Camlock 26sets</p> |  <p>B2: Wood dowel 18pcs</p> |  <p>B3: Handle with bolt 3sets</p> |
|  <p>B4: Stopper with screw 3sets</p> |  <p>B5: Screw 24pcs</p> |  <p>B6: Screw 12pcs</p> |
|  <p>B7: Anchor with screw 1set</p> |  <p>B8: Anti-tip kit 1set</p> | |




Step 1


B4:  3sets



Attach Stoppers (B4) to the bottom of Shelf (A5) using included Screws .




Step 2


| | | | |
|-----|---|---|-------|
| B1: |  |  | 4sets |
| B2: |  | | 2pcs |



Assemble Dividers (A6) to Shelf (A5) using Camlocks (B1) and Wood Dowels (B2).




Step 3


| | | | |
|-----|---|---|-------|
| B1: |  |  | 4sets |
| B2: |  | | 2pcs |



Assemble Bottom Panel (A4) to Dividers (A6) using Camlocks (B1) and Wood Dowels (B2).




Step 4


| | | | |
|-----|---|---|--------|
| B1: |  |  | 12sets |
| B2: |  | | 8pcs |



Assemble Aprons (A7), Shelf (A5) and Bottom Panel (A4) to Side Panels A1&A2 using Camlocks (B1) and Wood Dowels (B2).

Step 5


| | | | |
|-----|---|---|-------|
| B1: |  |  | 6sets |
| B2: |  | | 6pcs |



Assemble Top Panel (A1) to Side Panels (A2&A3) and Aprons (A7) using Camlocks (B1) and Wood Dowels (B2).

Step 6

B6:  12pcs




Attach Back Panel (A12) to the back of this unit using Screws (B6).

Step 7

X 3



B5:  12pcs




- 1): Insert Drawer Bottom Panel (A11) into the grooves on Drawer Front Panel (A8).
- 2): Attach Drawer Side Panels (A9) to Drawer Front Panel (A8) using Screws (B5), please make sure Drawer Bottom Panel (A11) inserted into the grooves on Drawer Side Panels (A9).

Step 8


X 3





| | | |
|-----|---|-------|
| B3: |  | 3sets |
| B5: |  | 12pcs |




- 1): Attach Drawer Back Panel (A10) to Drawer Side Panels (A9) using Screws (B5).
- 2): Attach Handle (B3) to Drawer Front Panel (A8) using included Screws .

Step 9



| | | | |
|-----|---|---|------|
| B7: |  |  | 1set |
| B8: |  |  | 1set |




Insert drawers into this table.


For your safety, please attached this unit to the wall by Anchor with screw (B7) and Anti-tip kit (B8)

APPENDIX: Dimension of Hardwares in this AI.

B1.




Cam-bolt




Cam-nut

B2.




Wood Dowel

B3.




Bolt for Handle

B4.




Screw for Stopper

B5.




Screw

B6.




Screw

B7.



Screw



Screw