


ASSEMBLY INSTRUCTION


ITEM : BENJAMIN FULL DAYBED

NO	PARTLIST	QTY
1	 BACK PANEL 1PC	1PC
2	 SIDE PANEL (L) 1PC	1PC
3	 SIDE PANEL (R) 1PC	1PC
4	 FRONT RAIL 1PC	1PC
5	 BACK RAIL 1PC	1PC
6	 SLAT 2SETS	2SETS
7	 LEG 4PCS	4PCS
8	 CENTER SUPPORT 1PC	1PC
9	 SUPPORT LEG 2PCS	2PCS

ITEM	HARDWARE	QTY
A	 JCBB SCREW M8 x 20MM 8PCS	8PCS
B	 JCBC SCREW M6 x 50MM 4PCS	4PCS
C	 SPRING WASHER M6 x 12MM 4PCS	4PCS
D	 FLAT WASHER M6 x 19MM 4PCS	4PCS
E	 SCREW M4 x 32MM 14PCS	14PCS
F	 L - KEY M4 x 65MM 1PC	1PC
G	 L - KEY M5 x 65MM 1PC	1PC


STEP 1

Begin assembly by attaching each Leg (7) to the bottom of Left Side Panel (2) & Right Side Panel (3).
Tighten the Legs (7) clockwise until secure.



STEP 2


Attach the Front Rail (4) and Back Rail (5) to the Left Side Panel (2) and Right Side Panel (3).
Aligning the holes and securing with 2 Allen Bolts (A) per each end by using L-Key (G).
(DO NOT FULLY TIGHTEN BOLTS FOR THIS STEP)



ASSEMBLY INSTRUCTION

STEP 3


Attach the Back Panel (1) to the Left Side Panel (2) and Right Side Panel (3), and securing with 2 Allen Bolts (B), 2 Spring Washer (C), 2 Flat Washer (D) each side of the Back Panel by using L-Key (F).



STEP 4

Secure 2 Support Leg (9) to the Center Support (8) as shown on step 4.1. Insert the pre-set metal on Slat Support (8) to the metal bracket on each of Side Panel (2) & (3) as shown on Step 4.2.

Then securing the metal bracket as shown in step 4.3 with 1 Screw (E) each side using Phillips Head Screwdriver (NOT INCLUDED).




ASSEMBLY INSTRUCTION


STEP 5

Tighten all Bolts on step 2 by using the L-Key (G) and following step 3 using L-Key (F) that has been provided.
Attach slats (6) to the Front Rail (4) and Back Rail (5) by Screwdriver unrolling and securing with 6 Screws (E)
per set using Phillips Head.

Repeat the same step to attach another set of Slats (6).



STEP 6



ASSEMBLY
COMPLETED