## ASSEMBLING & INSTALLATION INSTRUCTIONS PRODUCT# 20233 20237 20247 20247 20253 OUTDOOR CEILING LIGHT FIXTURE

WARNING! SHUT POWER OFF AT	FUSE OR CIRCUIT BREAKER.
<ul> <li>ASSEMBLING THE FIXTURE (Fig.2).</li> <li>1. Raise the candle sleeve on the lamp holder.</li> <li>2. Install the bulbs in accordance with the fixture's specifications. D NOT EXCEED THE MAXIMUM WATTAGE RATING!</li> <li>HANGING THE FIXTURE (Fig.1)</li> <li>1. Shut off the power at the circuit breaker and remove old fixtu from ceiling, including the old single bar.</li> <li>2. Carefully unpack new fixture and lay all the parts on a cle surface.</li> <li>3. Thread nipple (C) into loop (F) until snug.</li> <li>4. Thread other end of nipple (C) with loop attached into single b (D) until snug.</li> <li>5. Place lock washer (B) over end of nipple protruding through sing bar and thread hex nut (A) onto nipple until tight.</li> <li>6. Take this single bar assembly and mount to ceiling junction b with junction box screws (E). Tighten screws securely with screwdriver. The Junction box is not included.</li> <li>7. Using proper chain pliers to open one end link of the char provided and connect to the fixture loop (I). Close the link.</li> <li>8. By measuring, determine correct number of links needed for proper hanging height. Using proper chain pliers disconnect a discard remaining chain.</li> <li>9. Lace the fixture wires through the chain.</li> <li>10. Slip loop collar (H) over the chain, then do the same with t canopy (G).</li> <li>11. Open the other end link of the chain and hang the fixture on t loop at the ceiling. Close the link.</li> </ul>	Fig.1 Fig.1 Junction Box (Not included) A B C D C D E F C D F C D T D C D D C D D C D D C D D C D D C D D D D D D D D D D D D D
<ul> <li>loop at the ceiling. Close the link.</li> <li>12. Feed the fixture wires through the loop (F) and nipple (C) and pruntil taut.</li> <li>13. Slide canopy (G) up flush to ceiling, secure using loop collar(H).</li> <li><b>CONNECTING THE WIRES (Fig.3)</b></li> <li>1. Take the black wire from the ceiling junction box and the smooth wire leg from the fixture and twist bare ends together. Twist wire connector onto end of wire until snug.</li> <li>2. Repeat same process with white junction box wire and ribbed wire leg of fixture wire. NOTE: Twist wires together in the sare direction you twist the wire connector onto wires.</li> <li>3. If your junction box has a grounding wire (green or bare copper attach this wire and the bare copper wire from the fixture togeth as step 1. If junction box has no ground wire, attach the bare copper fixture wire to the green ground screw on the single bar.</li> <li>4. Tuck these wire connections neatly into the ceiling outlet box at then raise the canopy (G) all the way to the ceiling. Raise the loo (H) and thread onto ceiling loop protruding through canopy.</li> <li>Your installation is now complete. Return power to the junction box and test the fixture.</li> </ul>	All the
Fig.3 FIXTURE WIRES Black or Smooth HOUSE WIRES Wite or Ribbed HOUSE WIRES Bare Copper HOUSE WIRES Black WIRES Bare Copper HOUSE WIRES Black WIRES Bare Copper HOUSE WIRES Black WIRES Bare Copper HOUSE WIRES Black WIRES Bare Copper HOUSE WIRES Black WIRES Black WIRES Black WIRES Black WIRES Black WIRES Black WIRES Black WIRES Black WIRES Black WIRES Black WIRES Black WIRES Black WIRES Black WIRES Black WIRES Black WIRES Black WIRES Black White or Copper Cop	LIGHTING EST. 1993 DOC20141220233