



Encore Shower Door & Base

SHOWER DOOR & BASE INSTALLATION INSTRUCTIONS

IMPORTANT

DreamLine[®] reserves the right to alter, modify or redesign products at any time without prior notice. For the latest up-to-date technical drawings, manuals, warranty information or additional details please refer to your model's web page on **DreamLine.com**



STEP 1: Shower Base Installation Instructions

STEP 2: Shower Door Installation Instructions



Questions?

Please Call DreamLine Customer Support: **1-855-831-2126**
Hours of Operation M-F 8AM - 7PM EST and Saturday 9AM - 5PM EST

Support@DreamLine.com



For more information about DreamLine[®] Shower Doors, Tub Doors & Enclosures, please visit **DreamLine.com**




SLIMLINE SHOWER BASE

SHOWER BASE DIMENSIONS AND INSTALLATION INSTRUCTIONS

IMPORTANT!

DreamLine® reserves the right to alter, modify or redesign products at any time without prior notice. For the latest up-to-date technical drawings, manuals, warranty information or additional details please refer to your model's web page on DreamLine.com



Double Threshold Shower Base with Corner Drain Configuration
shown as an example

Color options:

- - White
- 22- Biscuit
- 88- Black

Please review this entire manual before beginning installation



Questions?

Please Call **DreamLine Customer Support: 1-855-831-2126**
Hours of Operation M-F 8AM - 7PM EST and Saturday 9AM - 5PM EST

Support@DreamLine.com



For more information about DreamLine® products please visit DreamLine.com


Preparation

1. Prior to installation, examine all boxes and packages for shipping damage and compare the piece count with your packing slip. After opening all boxes and packages read this introduction carefully. Check that all of the needed parts are included in the package by checking off the components on the "Detailed Diagram of Shower Door Components". If the unit has been damaged, has a finishing defect, or has missing parts, please contact our customer support department within **3 business days** of the delivery date. Please note that **DreamLine® will not replace any damaged products or missing parts free of charge after 3 business days or if the product has been installed.** Please contact DreamLine® if you have any questions and please provide an order number, job name or other proof of purchase to help identify the original order.
2. Install all of the required plumbing and drainage before installing the shower base. **Use a competent and licensed (if required by local code) plumber for all plumbing installation.**
3. **Shower bases must be installed by a licensed plumber. Please note that you should consult your local building codes with questions on installation compliance standards. Building and plumbing codes may vary by location and DreamLine® is not responsible for code compliance standards for your project.**
4. Make sure that prior to the installation the installation surface is leveled and solid and will be able to support the total weight of the unit. Also make sure the walls are at right angles. While some adjustment in leveling of the tray is possible, irregular installation surface level or improper angle of side walls will result in serious problems for your installation. Please note that some adjustments may be necessary during the installation process.
5. **Center drain configurations are centered on the width only. See technical drawing tables for drain locations.**
6. **Drain not included with this product.** The drain *opening* is 3-3/8" in diameter and **accepts a standard 2" compression fitted drain.**


IMPORTANT NOTE:

Dimensions provided are for reference only. Measure the actual shower tray before installation. This includes overall dimensions and drain location. Allowed tolerance for center of the drain is +/-1/2".

Tools Required



Tape
Measure



Pencil



Level





Mortar





When constructing or installing a shower base, consider how **the thickness of the wall treatment (wallboard, tile, etc.) will affect the finished opening size for the shower door.**

Compare the overall dimensions of the shower door model with the finished opening size before proceeding with the installation.







When constructing or installing a shower base, consider how **the thickness of the wall treatment (wallboard, tile, etc.) will affect where the shower enclosure will sit on the threshold.** Compare the overall outside dimensions of the shower enclosure model size with the finished threshold before proceeding with the installation.



SINGLE THRESHOLD SHOWER BASE



Center Drain Configuration



MODEL	SPECIFICATION	D (in)	W (in)	D1 (in)	W1 (in)
DLT-1132320	32" x 32"	32"	32"	15"	16"
DLT-1136360	36" x 36"	36"	36"	15"	18"
DLT-1132420	32" x 42"	32"	42"	15"	21"
DLT-1134420	34" x 42"	34"	42"	15"	21"
DLT-1136420	36" x 42"	36"	42"	15"	21"
DLT-1142420	42" x 42"	42"	42"	20"	21"
DLT-1132480	32" x 48"	32"	48"	15"	24"
DLT-1134480	34" x 48"	34"	48"	15"	24"
DLT-1136480	36" x 48"	36"	48"	15"	24"
DLT-1132540	32" x 54"	32"	54"	15"	27"
DLT-1134540	34" x 54"	34"	54"	15"	27"
DLT-1136540	36" x 54"	36"	54"	15"	27"
DLT-1130600	30" x 60"	30"	60"	15"	30"
DLT-1132600	32" x 60"	32"	60"	15"	30"
DLT-1134600	34" x 60"	34"	60"	15"	30"
DLT-1136600	36" x 60"	36"	60"	15"	30"

SINGLE THRESHOLD SHOWER BASE



Left-Hand Drain Configuration



MODEL	SPECIFICATION	D (in)	W (in)	D1 (in)	W1 (in)
DLT-1130601	30"×60"	30"	60"	15"	12"
DLT-1132601	32"×60"	32"	60"	15"	12"
DLT-1134601	34"×60"	34"	60"	17"	12"
DLT-1136601	36"×60"	36"	60"	18"	12"



SINGLE THRESHOLD SHOWER BASE

Right-Hand Drain Configuration





MODEL	SPECIFICATION	D (in)	W (in)	D1 (in)	W1 (in)
DLT-1130602	30"×60"	30"	60"	15"	12"
DLT-1132602	32"×60"	32"	60"	15"	12"
DLT-1134602	34"×60"	34"	60"	17"	12"
DLT-1136602	36"×60"	36"	60"	18"	12"

NEO ANGLE SHOWER BASE



MODEL	SPECIFICATION	W (in)	A (in)	B (in)	C (in)
DLT-2036360	36"×36"	36"	18 5/16"	25"	12"
DLT-2038380	38"×38"	38"	20 5/16"	25"	12"
DLT-2040400	40"×40"	40"	22 5/16"	25"	14 3/8"
DLT-2042420	42"×42"	42"	24 5/16"	25"	14 3/8"



QUARTER ROUND SHOWER BASE



MODEL	SPECIFICATION	W (in)	C (in)	R (in)
DLT-7033330	33"×33"	33"	12"	21 5/8"
DLT-7036360	36"×36"	36"	12"	21 5/8"
DLT-7038380	38"×38"	38"	12"	21 5/8"

DOUBLE THRESHOLD SHOWER BASE



Corner Drain Configuration



MODEL	SPECIFICATION	W (in)	C (in)
DLT-1032320	32"×32"	32"	12"
DLT-1036360	36"×36"	36"	12"

DOUBLE THRESHOLD SHOWER BASE



Left-Hand Drain Configuration



MODEL	SPECIFICATION	D (in)	W (in)	D1 (in)	W1 (in)
DLT-1034481	34"×48"	34"	48"	17"	12"
DLT-1036481	36"×48"	36"	48"	18"	12"
DLT-1036541	36"×54"	36"	54"	18"	12"
DLT-1036601	36"×60"	36"	60"	18"	12"


DOUBLE THRESHOLD SHOWER BASE

Right-Hand Drain Configuration



MODEL	SPECIFICATION	D (in)	W (in)	D1 (in)	W1 (in)
DLT-1034482	34"×48"	34"	48"	17"	12"
DLT-1036482	36"×48"	36"	48"	18"	12"
DLT-1036542	36"×54"	36"	54"	18"	12"
DLT-1036602	36"×60"	36"	60"	18"	12"

Shower Base Cross Section Diagram



Shower Base Installation - Preparation

1. Ensure that the floor and the studs are at right angles.
Provide a 5"×5" opening in the sub-floor for the drain.
The 2" PVC waste pipe should extend above the surface of the sub-floor according to the drain installation instructions and the height of the Shower base.
Refer to the product drawings and tables in this installation manual for the drain location.

See Fig. 1 and Fig. 2 for details.




Fig. 1




Fig. 2

2. Install the shower drain (**NOT INCLUDED**) according to the drain installation manual (supplied with the drain).

See Fig. 3 for example





Fig. 3

3. Place the tray into the designated position so that the Drain cutout drops around the Drain Pipe and butt the Shower Base up against the studs.

See Fig. 4 for details.



Lower the base over the drain pipe and set it into place against the studs.

Fig. 4

- Level the tray and place marks on the studs above the upper edge of the tile flange.

See Fig. 5 for details.




Fig. 5

- Mix the bedding material (Mortar, cement-sand mix, etc.) **Concrete or plaster is not recommended.** Apply enough bedding material to support the entire bottom of the shower base. This will add additional stability and prevent the base from shifting position.

See Fig. 6 for details.




Fig. 6

6. After the bedding material has been poured and *before* it sets, place the shower base into the position with the drain assembly sliding over the PVC waste pipe. It will be necessary to push the shower base until the top of the tile flange aligns with the marks drawn on the studs and the front edge is contacting the rough floor along the entire length of the shower base. Ensure that the base is level in all directions. You may need to use shims to hold the tray level until the bedding fully sets. Remove all excess mortar.




Fig. 7

7. Allow the bedding material to completely harden before applying weight to the bottom of the shower base.

Install the cement board (or the wallboard) above the tile flanges and secure it to the studs. Put the tiles (or other finishing wall material) over the cement board leaving 1/8" gap between the bottom of the tile or wall kit and the shower base. Use caulk to fill the gap.

See Fig. 8 and Fig. 9 for details.




Fig. 8




Fig. 9

Product Maintenance

BASES and BACKWALLS: To ensure long lasting life for your acrylic base and/or back walls: wipe them off after each use with a soft cloth. To clean the acrylic base or back walls use non-abrasive sprays or cream based cleaners. Avoid the use of aerosol spray cleaners. Never use abrasive cleansers, metal brushes or scrapers that could scratch or dull the surface.

GLASS: To ensure long lasting life for your glass shower products: wipe them off after each use with a soft cloth. Rinse and wipe off the glass using either a soft cloth or a squeegee to prevent soap buildup and water spots (Hard water can etch the surface of the glass over time if left to dry). To prevent scratching the surface: never use abrasive cleaners or cleaning products that contain scouring agents. Never use bristle brushes or abrasive sponges that may scratch the surface.

HARDWARE: To ensure a long lasting finish: wipe off the metal parts after each use with a soft cloth. Do not use abrasive cleaners or cleaning products containing ammonia, bleach or acid. If accidentally used, rinse the surface as soon as possible to prevent damage to the finish (peeling or corrosion). After cleaning the polished finishes, rinse thoroughly and wipe dry with a soft cloth.

Clean stainless steel surfaces at least once a week. When applying stainless steel cleaner or polish to stainless steel hardware, work with (not across) the grain. Never use an abrasive sponge or cloth, steel wool or wired brush as these may permanently scratch the surfaces.

NOTE: To maximize the life of your door, it is important to regularly inspect the glass and other hardware for misalignment, proper attachment, and/or damage. Contact DreamLine with any questions or concerns.



TEL: [866-731-2244](tel:866-731-2244)

FAX: [866-857-3638](tel:866-857-3638)

DREAMLINE.COM

For more information on [DreamLine® Shower Doors](http://DreamLine.com) and [Enclosures](#) please visit DreamLine.com

DREAMLINE®

THE ULTIMATE SHOWER DOOR

ENCORE / BRAVO

SHOWER AND TUB DOOR INSTALLATION INSTRUCTIONS

IMPORTANT

DreamLine® reserves the right to alter, modify or redesign products at any time without prior notice. For the latest up-to-date technical drawings, manuals, warranty information or additional details please refer to your model's web page on **DreamLine.com**

MODEL #s

SHDR-1660580-##

SHDR-1648760-##

SHDR-1654760-##


SHDR-1660760-##

##=finish

01- Chrome

04- Brushed Nickel

06- Oil Rubbed Bronze



Questions?

Please Call **DreamLine Customer Support: 1-855-831-2126**
Hours of Operation M-F 8AM - 7PM EST and Saturday 9AM - 5PM EST

Support@DreamLine.com



For more information about DreamLine® Shower Doors & Tub Doors please visit **DreamLine.com**



This model is treated with DreamLine's exclusive ClearMax™ Glass technology. This is a specially formulated coating that prevents the build up of soap and water spots.

Install the surface with the ClearMax™ label towards the inside of the shower. Please note that depending on the model, the glass may be coated on either one or both surfaces.

For best results, squeegee the glass after each use and dry with a soft cloth.

Preparation

1. Prior to installation, examine all boxes and packages for shipping damage and compare the piece count with your packing slip. After opening all boxes and packages read this introduction carefully. Check that all of the needed parts are included in the package by checking off the components on the "Detailed Diagram of Shower Door Components". If the unit has been damaged, has a finishing defect, or has missing parts, please contact our customer support department within **3 business days** of the delivery date. **Please note that DreamLine® will not replace any damaged products or missing parts free of charge after 3 business days or if the product has been installed.** Feel free to contact DreamLine™ if you have any questions, and please provide an order number, job name or other proof of purchase to help us identify your original order.

2. **Please note that you should consult your local building codes with questions on installation compliance standards. Building and plumbing codes may vary by location, and DreamLine® is not responsible for code compliance standards for your project and will not accept any returns.**

3. If this unit is going to be installed in a new construction, please install all of the required plumbing and drainage before installing the shower. **Use a competent and licensed (if required by local code) plumber for all plumbing installation.**

4. Please make sure that prior to beginning the installation, the surfaces are leveled and solid and will be able to support the total weight of the unit. Also make sure the walls are at right angles. Irregular installation surface level, radius corners or improper angle of side walls will result in serious problems for your installation. Please, note that some adjustments and drilling might be necessary during the installation process.

5. Please protect all primary surfaces of the product during installation. Never set your glass down directly onto a tile floor. Leave corner protectors in place until necessary to remove them. Always use a piece of wood or cardboard to protect the bottom edge and corners of the glass prior to and during installation.

6. **This unit must be installed upon a finished threshold and against finished walls.**

7. **This model can accommodate up to 3/8" per wall profile for out-of-plumb conditions. Verify that the walls are plumb before proceeding with the installation.**

8. **This model requires that you drill into the threshold for proper installation.**


9. **This model requires a minimum 2-1/4" of flat threshold space for installation.**

10. **This model requires two people for installation.**


11. **Professional installation recommended.**

NOTE: This manual will describe the shower door installation. Please follow the same sequence of installation steps for the tub door installation.

Tools




Level



Tape Measure



Pencil




Phillips Screwdriver




Drill bit (Ø=5/16")



Drill bit (Ø=1/8")




Silicone




Metal File




Power Drill



Hammer




Miter saw or Hacksaw



NOTE: Unpack your unit carefully and inspect it. Lay it out and identify all parts using the detailed diagram and packing list in your manual as a reference. Before discarding the carton, check for small hardware bags that may have fallen to the bottom of the box. If any parts are damaged or missing, please contact DreamLine™ for replacement. The shipping boxes may contain extra parts not used in your model configuration.

NOTE: Retain these installation instructions for future reference.

Detailed Diagram of shower door components



The glass surface with the ClearMax™ label must be installed to face inside of the shower

Parts List

#	ITEM	Qty	#	ITEM	Qty
1	Wall Profile	2pcs	9	Ø8 Plastic Wall Anchor	6pcs
2	Upper Guide Rail	1pc	10	Countersunk Head Screw ST4.2×40	4pcs
3	Door Glass	2pcs	11	Truss Head Self-Tapping Screw 4.2x10	4pcs
4	Wall Profile Bumpers	4pcs	12	Truss Head Self-Tapping Screw 4.2x16	2pcs
5	Guide Block	1pc	13	Truss Head Self-Tapping Screw 4.2x30	2pcs
6	Roller Assembly	4pcs	14	Allen Wrench 3mm	1pc
7	Upper Guide Rail Connector	2pcs	15	Bottom Guide Rail	1pc
8	Towel Bar	2pcs			

Boxes

#	Box	Box Contents by part#
1	Glass Box (GL)	3
2	Aluminum Acc Box (AC)	1. 2. 4. 5. 6. 7. 8. 9. 10. 11. 12.13
3	Spare Acc parts bag	12. 13 one each; 9. 10. 11 three each.

Installation steps

1. Measure the finished opening width at the bottom and at the top (at the model height: 58" for tub or 76" for shower). Use these dimensions as "**W**" in step #2.

Also check the threshold for level and the walls for plumb.

See Fig 1 for details




Fig 1

2. Using a miter saw or hacksaw, cut the **Upper Guide Rail (#02)** $1/16''$ shorter than the top dimension **W** from step #1. ($W - 1/16'' = \text{finished cut length } L$) (see Fig 2a)

The **Bottom Guide Rail (#15)** needs to be cut equally from both ends to keep the center guide holes centered. (The **Bottom Guide Rail (#15)** has been precut for the model size. See Table A). Using a miter saw or hack saw, cut the **Bottom Guide Rail (#15)** $3/4''$ shorter than the bottom dimension **W** from step #1. ($W - 3/4'' = \text{finished cut length } L$) (see Fig 2b)

See Fig 2a & 2b for details




Fig 2a

Note: The **Bottom guide rail (#15)** needs to be shorter than the **Upper guide rail (#02)** because it fits between the wall profiles, while the upper guide rail fits wall-to-wall.

Table A

Model Size	Precut Bottom Rail Length
60" x 76"	59-3/8" (1508mm)
48" x 76"	47-3/8" (1203mm)
54" x 76"	53-3/8" (1356mm)
60" x 58"	59-3/8" (1508mm)

FOR EXAMPLE: If the finished opening $W = 59''$, then $59'' - 3/4'' = 58-1/4''$ finished cut length " L " will be $58-1/4''$. (The Bottom rail length for the 60" model = $59-3/8'' - 58-1/4'' = 1-1/8''$ $1-1/8''$ divided by 2 = $9/16''$ Cut $9/16''$ off from each end to a finished cut length of $58-1/4''$).

Note that this is only an example and the actual cut-off amount will vary based on the actual finished opening dimension.




Fig 2b

3. Place the **Bottom Guide Rail (#15)** onto the threshold in the desired position. Use a tape measure to align it evenly with the front edge of the threshold and mark its position on the threshold.

TIP: Use the left and right **Wall profiles (#01)** to center the **Bottom Guide Rail (#15)** on the threshold to maintain the proper spacing from the walls.

See Fig 3 for details




Fig 3

4. Attach the **Upper guide rail connectors (#07)** to the top of both **Wall Profiles (#01)** using the **ST4.2 x 30 Truss head screws(#13)**. (Fig 4a)

Position one **Wall Profile (#01)** against the wall onto the **Bottom Guide Rail (#15)** . Check for plumb with a level and mark the position. Mark both holes in the **Upper Guide Rail Connector (#07)** for drilling. (Fig 4b). Remove the wall profile and drill **Ø 5/16"** holes and insert the **Wall anchors (#09)**.

See Fig 4a and 4b for details

TIP: Add a few drops of dish soap to the screws to make installation easier.




Fig 4a







Fig 4b

5. Apply silicone to the back of the **Wall Profile (#01)** and place it back into position on the wall. Attach the **Upper Guide Rail Connector (#07)** using two each of the **ST4.2 x 40 Countersunk Flathead Screws (#10)**. Attach two of the **Wall Profile Bumpers (#04)** using the **ST4.2 x 10 screws (#11)** and cover the holes with the decorative caps.

See Fig 5 for details






Fig 5

6. Position the **Bottom guide rail (#15)** on the threshold and mark the threshold through the center guide holes for drilling.

Remove the **Bottom guide rail (#15)** and drill into the threshold:

- Drill **Ø1/8"** holes for installation into an acrylic threshold
- Drill **Ø5/16"** holes and use anchors for installation into a tile threshold.

Apply silicone to the bottom surface of the **Bottom guide rail (#15)** and place it back into position on the threshold.

Attach the **Guide block (#05)** and **Bottom guide rail (#15)** to the threshold using two of the **ST4.2 x16 screws (#12)**. Cover the screw holes with the decorative caps.

See Fig 6 for details





Fig 6

7. Position the remaining **Wall Profile (#01)** against the wall onto the **Bottom Guide Rail (#15)**. Check for plumb with a level and mark the position. Mark the holes in the **Upper Guide rail connector (#07)** for drilling. (Fig 7.1)
Remove the wall profile and drill $\text{Ø } 5/16''$ holes and insert the **Wall Anchors (#09)**.

See Fig 7 for details





Fig 7

8. Apply silicone to the back of the **Wall Profile (#01)** and place it back into position on the wall. Attach the **Upper Guide rail connector (#07)** to the wall using two each of the **ST4.2 x 40 Countersunk flathead screws (#10)**.

Attach two of the **Wall Profile bumpers (#04)** using the **ST4.2 x 10 screws (#11)** and cover the holes with the decorative caps.

See Fig 8 for details





Fig 8



9. Install the **Upper Guide Rail (#02)** onto the installed **Wall profiles (#01)** making sure that it sits firmly onto the **Wall profile connectors (#07)**.

See Fig 9 for details





Fig 9

Note:

Do not attach the **Towel bars (#08)** to the **Door glass (#03)** until instructed.

Do not attempt to lift the glass with the towel bars as doing so may cause damage to the glass and/or serious personal injury. Use an assistant or a professional grade glass suction cup to handle the glass.

10. Install the **Roller Assemblies (#06)** onto the tops of both doors. Be sure to position the rollers facing in the correct direction for each door - both wheels facing 'out' for the outside door glass, and both wheels facing 'in' for the inside door glass. Bring both lites of **Door glass (#03)** into the shower area for hanging. Using padding to protect the glass and shower area.

See Fig 10 for details




Fig 10

11. Have an assistant carefully lift one end of the **Upper Guide Rail (#02)** about one inch - just to the top of the **Upper Guide Rail Connector (#07)**.

See Figs 11 and 12 for details




Fig 11





Fig 12


12. Using an assistant to support the **Upper Guide Rail (#02)**, lift and insert the outer door glass up into the **Upper Guide Rail (#02)** so the **Roller Assemblies (#06)** fit into the groove inside the rail. Carefully lower the **Upper Guide Rail (#02)** so the door glass slides into the proper slot in the **Guide block (#05)**.

See Fig 13 for details




Outside door

Fig 13




13. Next, install the inner door glass in the same manner. Move the installed door to the opposite end, lift the **Upper Guide Rail (#02)**, and install the inner door glass into the **Upper Guide Rail (#02)** and into the **Guide block (#05)**.

See Fig 14 for details



Inside door

Fig 14



14. To compensate for minor out-of-plumb conditions (up to 3/8"): After both doors are installed, use the **Allen Wrench (#14)** to make minor adjustments with the **Roller Assemblies (#06)** as necessary. Remove the cover plate, then loosen the mounting bolt on the roller. Rotate the adjustment bolt on the bottom of the wheel assembly to tilt the door glass to the desired position. Re-tighten the mounting bolt and replace the cover plate.

See Fig 15 for details






Fig 15



Use the adjustment bolt on the roller assemblies to adjust the door glass

15. Install both the inside and outside **Towel bars (#08)** using all provided gaskets as shown. Cover the bolt with the decorative cap.

See Fig 16 for details




Fig 16

16. Apply good quality mildew-resistant silicone to the entire interior perimeter where the wall profile meets the wall and along the threshold.

Allow 24 hours for the silicone to fully cure before using the shower.

See Fig 17 for details




Fig 17

Product Maintenance

BASES and BACKWALLS: To ensure long lasting life for your acrylic back walls: wipe them off after each use with a soft cloth. To clean the acrylic back walls use non-abrasive sprays or cream based cleaners. Avoid the use of aerosol spray cleaners. Never use abrasive cleansers, metal brushes or scrapers that could scratch or dull the surface.

GLASS: To ensure long lasting life for your glass shower products: wipe them off after each use with a soft cloth. Rinse and wipe off the glass using either a soft cloth or a squeegee to prevent soap buildup and water spots (Hard water can etch the surface of the glass over time if left to dry). To prevent scratching the surface: never use abrasive cleaners or cleaning products that contain scouring agents. Never use bristle brushes or abrasive sponges that may scratch the surface.

HARDWARE: To ensure a long lasting finish: wipe off the metal parts after each use with a soft cloth. Do not use abrasive cleaners or cleaning products containing ammonia, bleach or acid. If accidentally used, rinse the surface as soon as possible to prevent damage to the finish (peeling or corrosion). After cleaning the polished finishes, rinse thoroughly and wipe dry with soft cloth. Clean stainless steel surfaces at least once a week. When applying stainless steel cleaner or polish to stainless steel hardware, work with (not across) the grain. Never use an abrasive sponge or cloth, steel wool or wired brush as these may permanently scratch the surfaces.

NOTE: To maximize the life of your door, it is important to regularly inspect the glass and other hardware for misalignment, proper attachment, and/or damage. Contact DreamLine with any questions or concerns.



TEL: 866-731-2244
FAX: 866-857-3638
DREAMLINE.COM

For more information on DreamLine[®] Shower Doors and Enclosures please visit **DreamLine.com**