


ARTISWALL®

INSTALLATION INSTRUCTIONS

TOOLS REQUIRED


Tape Measure, Pencil, Utility Knife, Scissors, Straight Edge

1




Unbox planks and let them sit in room of install for 10 days to acclimate. Just like you would do with a wood floor.

2




Clean your wall. Damp paper towels will do the trick.

3




Cut the AIM strips to length and apply them to your wall every 10 inches.

4



Apply the planks to your wall. We recommend starting from the bottom and working your way up.

5



Trim the planks to fit your wall. Score both sides of the plank with a utility knife and snap.

6



Enjoy your beautiful new accent wall.

Pro Tip

Use a credit card to create a small gap between the planks. The planks will expand and fill the gaps in a week.

NEED HELP?

For a detailed instruction video visit: artiswall.com/how-to-artis-wall/
(888) 694-7181