


ASSEMBLY INSTRUCTIONS



NOTE TO CUSTOMERS:

- For ease and speed of assembly we recommend that before you commence each step of the assembly that you identify all the parts required to complete that step.
- We recommend that where possible you allow sufficient space to assemble the item as close as possible to the place where it will be once assembled.
- For the protection of your furniture we recommend that the product is placed on protected surfaces during assembly to prevent any damage.
- During assembly do not over tighten, as this may damage the product.
- Please ensure you retain all the product packaging until the item completely assembled.
- Please periodically check all fittings and re-tighten as necessary.
- Please never allow any liquids to remain on your furniture as absorption can cause the wood to warp or finish to de-laminate.

To insert a cam lock: (Please read below instructions before assembling)




Diagram A

1. Insert cam screw into hole as shown in diagram A .




Diagram B

Make sure not to insert the cam screw:
Too deep as shown in figure B as this will cause the
cam screw to be misaligned and unable to
interlock properly.






Diagram C


Also avoid inserting the cam screw too close to the
surface of the hole as shown in figure C, as this will
cause the cam lock to be too loose, and not interlock
properly.



2. Connect the panels together.



3. When inserting the cam lock make sure the arrow
of the cam lock faces the cam screw.




4. To tighten the cam lock turn the cam lock clockwise
90-180 degree or until the arrow is facing opposite
the place cam lock was inserted.

NOTE: DO NOT USE AN AUTOMATIC
SCREWDRIVER TO TIGHTEN CAM LOCKS.


Note:

- Read these instructions carefully before assembling.
- Tools required : Phillips screwdriver, flat screwdriver.
- Find a clean, smooth area on which to work , such as a carpet, in order to avoid scratching the wood surfaces.
- Wait to dispose of the packing material until assembly is complete and all parts and hardware are accounted for.
- Two or more people might be required for assembly.


Parts list :




A1 1PC Top Panel




A2 1PC Left Side Panel




A3 1PC Right Side Panel




A4 1PC Middle Divider




A5 1PC Bottom Panel



A6 1PC Small Divider




A7 1PC
Drawer Front Panel




A8 2PCS
Drawer Side Panel




A9 1PC
Drawer Back Panel




A10 1PC
Drawer Bottom Panel



A11 1PC
Door Panel



A12 1PC
Adjustable shelf




A13 2PCS
Shelf




A14 1PC
Back Panel

Hardware list :



B1 24 Sets
Camlock




B2 12 Pcs
Wood Dowel



B3 8 Pcs
Screw




B4 1 Set
Handle Of
Drawer



B5 1 Set
Handle Of
Door



B6 4 Pcs
Screw



B7 1 Set
Magnet With
Screw




B8 4 Pcs
Support



B9 2 Pcs
Wheel



B10 2 Pcs
Wheel With
Lock




B11 1 Set
Stopper




B12 1 Pc
Wrench

Step 1: Attach Stopper B11 to the top of Small Divider A6 using included screw.

Step 2: Assemble Small Divider A6 and Shelves A13 to Middle Divider A4 using Camlocks B1





Step 3: Assemble Bottom Panel A5 to Divider A4 using Camlocks B1 and Wood Dowels B2.





Step 4: Assemble Left Side Panel A2 to Small Divider A6 using Camlocks B1 and Bottom Panel A5 using Camlocks B1 and Wood Dowels B2..

Step 5: Assemble Right Side Panel A3 to Shelves A13 using Camlocks B1 and Bottom panel A5 using Camlocks B1 and Wood Dowels B2.






Step 6: Insert Back Panel A14 into the grooves on Left Side Panels A2 , Middle Divider A4 and Bottom Panel A5.

Step 7: Attach Magnet B7 to Middle Divider A4 using included Screws.






Step 8: Assemble Top Panel A1 to Side Panels A2 & A3 and Middle Divider A4 using Camlocks B1 and Wood Dowels B2 .




B1:		6 Sets
B2:		6 Pcs




Step 9: Attache Door Handle B5 to Door Panel A11 using included Bolts.
 Step 10: Assemble Door Panel A11 to Left Side Panel A2 using Screws B6.

B5:		1 Set
B6:		4 Pcs



Step 11: Screw Wheels B9 and B10 to Bottom Panel A5 using Spanner B12.





B9:		2 Pcs
B10:		2 Pcs
B12:		1 Pc



Step 12: Assemble Drawer Side Panels A8 to Drawer Front Panel A7 using Screws B3.

Step 13: Insert Drawer Bottom Panel A10 into the grooves on Drawer Side Panels A8 and Drawer Front Panel A7.


Step 14: Assemble Drawer Back Panel A9 to Drawer Side Panels using Screws B3.

Step 15: Attach Drawer Handle B4 to Drawer Front Panel using included Bolts.

B3:		8 Pcs
B4:		1 Set












Step 16: Insert Shelf Support B8 into the holes on Left Side Panel A2 and Middle Divider A4. Then put Adjustable Shelf A12 onto Shelf Support B8.



B8:  4 Pcs

APPENDIX: Dimension of Hardwares in this AI.

<p>B1</p>  <p>Cam-bolt</p>	<p>B2</p>  <p>Cam-nut</p>	<p>B2</p>  <p>Wood Dowel</p>
<p>B3</p>  <p>Screw</p>	<p>B4</p>  <p>Bolt for drawer handle</p>	<p>B5</p>  <p>Bolt for door handle</p>
<p>B6</p>  <p>Screw</p>	<p>B7</p>  <p>Screw for magnet</p>	<p>B11</p>  <p>Screw for stopper</p>