



**1** Attach piece 3 & 4 to piece 5 using wooden dowels (C), cam dowels (A) and cam locks (B).




A		8 PCS
B		8 PCS
C		12 PCS
D		4 PCS
E		1 PC
F		1 PC
G		6 PCS
H		1 PC
I		1 PC
J		2 PCS
K		1 PC

L		1 PC
M		4 PCS
N		12 PCS
O		4 PCS


**2** Then attach piece 1 using wooden dowels (C), cam dowels (A) and cam locks (B), tighten the cross dowels.




**3** Turn the unit upside down, slot in piece 7 to the built-in ridges. Secure the catch (F) using screws (G). Use the pre-drilled holes for guidance.




**4** On piece 6, attach the plates (K) using screws (L), attach the door handles (H) using screws (I). Attach piece 2 to the unit using wooden dowels (C), screws (D) with tools (E). Connect door 6 using bar hinges (J).



**5** Attach 4 x Leg (H) to piece 2 using screw (N) with tools (E).



**6** Attach panel stiffener (O) on piece 7 using screw (G).



**7** The unit should now be assembled and ready to use.

