






MULTIMO



















A 225 BELLEZA TWIN




Assembly Instructions


Track Title	Piece	(inch)			(mm)			
		Thickness	Length	Width	Piece	Thick	Height	Most
A		1,18	89,76	17,32	2	30	2280	440
B		1,18	41,57	17,32	1	30	1056	440
C		0,71	41,57	15,75	2	18	1056	400
D		0,71	41,57	10,24	1	18	1056	260
E		0,71	41,57	5,43	1	18	1056	138
F		1,18	40,87	4,33	1	30	1038	110
G		1,38	40,87	19,69	1	35	1038	500
H		0,71	81,89	40,71	1	18	2080	1034
K		0,31	88,86	14,02	3	8	2257	356

Accessories List

MNX 02  22 piece IM - 01 (6x30) mm	MNG - 01  22/ piece AL - 01	OT-054  2 / piece AL - 02	CT - 01 (6x40) mm  2 / piece DSE - 01 (40x90x32) mm
 4 / piece DD - 01 (R10)	 4 VD - 01(6X70) mm	 5 PL - 01 (6x19x2) mm	 2/ piece VDA - 01 (6,5x50) mm
 2 / piece VTB - 01 (4,8x16) mm	 2/ piece KP - 01 (224) mm	 3 / piece VKP - 01 (22) mm	 4 / piece VD - 02 (3,5x25) mm
 12 / piece KVL 01	 2 / piece MKZ - 02	 4 / piece TTC 01	 20 / piece SC - 34
 2 / piece H 01	 22/ piece TAP - 01		




STEP 1



210°

STEP 2




210°



STEP 3




MNG - 01




STEP 4

210°




MNG - 01


STEP 5




STEP 6




STEP 7



STEP 8



STEP 9




x12




VD - 02





STEP 10






STEP 11



STEP 12



CAUTION
DO NOT UNLOCK BEFORE INSTALL



STEP 13



Ø 10 mm / 0,254 inch


DD - 01

PL - 01

VD - 01

VTB - 01

DSE - 01




STEP 13

Ø 10 mm / 0,254 inch





FIRST LOCATE THE STUDS BY USING "STUD FINDER" IN THE WALL AND DRILL IT
ACCORDING TO THE HEIGHT MEASUREMENTS
GIVEN ON THE SIDE.
UPPER HOLES SHOULD BE DRILLED
FOR ATTACHING BED AT NEXT STEP.




SUPPLY DRYWALL FASTENERS APPROPRIATE
TO YOUR WALL TYPE. WE RECOMMEND
USING STEEL TOGGLE BOLT ANCHOR THAT
SHOWN BELOW




STEP 14



STEP 15




STEP 16





STEP 17




VKP - 01



HANDLE MOUNTING
OPTION A



HANDLE MOUNTING
OPTION B



ATTENTION / HOW TO / READ ME / OWNER'S GUIDE

1. When mounting on a regular drywall, furniture must be fastened to wood or metal studs. Solid walls made of brick, concrete or similar strong material are also acceptable. Do not mount furniture to paper-mache or sheetrock like material without properly affixing to stud.
2. For safety and product longevity you must periodically inspect the mounting and mechanical connections for integrity and tightness. Confirm hardware remains properly affixed and connections snug.
3. Wall Bed mattress thickness may not exceed 8 inch. Take care to remove pillows and excess blankets before closing. Doing so keeps mechanism free of obstruction and unnecessary stress.
4. Do not lean or rest heavy objects on side or top of furniture. This may cause balance issues and compromise the integrity of your mounting connections.
5. Please use the furniture's beds, desks and shelving as intended. Not designed to be sat, stood, leaned, jumped (etc) on. Improper use may cause personal injury and damage to property.
6. With seasonal humidity change you must inspect interior and exterior of furniture.
7. Single, Twin, Twin XL beds accommodate the weight of one person. Improperly sleeping more than one person risks injury to person and damage to property.
8. Before any un-mounting or disassembly please contact Multimo for technical support and instruction. Failure to properly detach risks injury to person and damage to property.
9. For Bunk Beds:
 - a. Always use provided ladder when accessing top bunk.
 - b. Be slow, careful and aware of surroundings when opening top bunk.
 - c. Do not horseplay. Beds are to be slept on only.
 - d. Some have legs that fully extend when open- be aware of where the leg is and will be.



www.multimobeds.com