

**WALKER EDISON**  
TM

## Annette Contemporary 6-Drawer Dresser Wood

SKU# WEANN026D1



**For Residential Use Only**

Please visit our website for the most current instructions, assembly tips, report damage, or request parts. [www.walker-edison.com](http://www.walker-edison.com)




# Time to get started

Set up a clean and soft workplace to get started and avoid damage during the assembly. It also helps to double-check that you've got all the pieces and parts before diving in to assembly.

---


## Estimated time for assembly



---

## People recommended for assembly

Make it a team effort! Grab a friend for quicker, easier assembly.




2 People Build

---

## Tools Needed


Grab a Phillips head screwdriver to conquer this assembly



---

## Use power tools with caution


You can cause cracking or damage to the material and easily strip the hardware. If you choose to use a power tool, your product will no longer be covered under Walker Edison's warranty.



---

## Glue is provided to secure wood dowels in place




When inserting dowels, locate the appropriate hole, place a small amount of glue in the hole, and then insert the dowel. Wipe away excess glue immediately.



**Scan to get assembly tips and help!**














# WE Parts List

| Part Number | Description              | Quantity |
|-------------|--------------------------|----------|
| 1           | Top Panel                | 1        |
| 2           | Bottom Panel             | 1        |
| 3           | Left Side Panel          | 1        |
| 4           | Right Side Panel         | 1        |
| 5           | Divider Panel            | 1        |
| 6           | Front Rail               | 2        |
| 7           | Upper Back Panel         | 1        |
| 8           | Lower Back Panel         | 1        |
| 9           | Leg                      | 4        |
| 10          | Middle Foot              | 1        |
| 11          | Top Drawer Front Panel   | 2        |
| 12          | Top Drawer Back Panel    | 2        |
| 13          | Top Drawer Left Panel    | 2        |
| 14          | Top Drawer Right Panel   | 2        |
| 15          | Lower Drawer Front Panel | 4        |
| 16          | Lower Drawer Back Panel  | 4        |
| 17          | Lower Drawer Left Panel  | 4        |
| 18          | Lower Drawer Right Panel | 4        |
| 19          | Drawer Bottom Panel      | 6        |











# Hardware List

| Part | Size   | Name          | Quantity |
|------|--|---------------|----------|
| A    |  8x30mm       | Wooden dowel  | 26       |
| B    |  6x30mm       | Wooden dowel  | 32       |
| C    |  6x35mm       | Cam bolt      | 26       |
| D    |  15x11mm      | Cam lock      | 26       |
| E    |  30mm        | Sticker       | 26       |
| F    |             | Handle        | 6        |
| G    |  5/32"x19mm | Screw         | 12       |
| H    |  1/4"x50mm  | Bolts         | 8        |
| J    |  1/4"       | Lock washer   | 8        |
| K    |  1/4"x16mm  | Washer        | 8        |
| L    |  M4         | Hex key       | 1        |
| M    |             | Plastic wedge | 10       |
| N    |  3x17mm     | Screw         | 10       |




## Hardware List

| Part | Size   | Name          | Quantity |
|------|--|---------------|----------|
| P    |  4x38mm | Screw         | 8        |
| Q    |  4x25mm | Screw         | 2        |
| R    |  4x12mm | Screw         | 2        |
| S    |         | Plastic strap | 2        |
| T    |         | Anchor        | 2        |
| U    |       | Glue Tube     | 2        |

*The hardware quantities listed above are required for proper assembly.  
Extra hardware pieces may be included.*






# Step 1

Let's get started! Screw six Cam bolts (C) into the Top Panel (1).



# Step 2


Screw two more Cam bolts (C) into the Lower Back Panel (8). Then, use the Glue (U) to secure the Wooden dowels (A) into the Lower Back Panel (8) and both Front Rails (6).



- 1: The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.
- 2: In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.

# Step 3


Insert Wooden dowels (A) into the top and bottom of the Left and Right Side Panels (3 & 4). Then, screw Cam bolts (C) into the Left and Right Side Panels (3 & 4).






# Step 4

Insert Wooden dowels (A) into the top and bottom of the Divider Panel (5).




# Step 5

Now, attach the Legs (9) to the Bottom Panel (2) using the Bolts (H) with a Lock Washer (J) and Washer (K). Also, screw the Middle Foot (10) into the center of the panel.





# Step 6

Turn the Bottom Panel (2) over and screw in the Cam bolts (C).



# Step 7


Now let's attach the Divider Panel (5) to the Lower Back Panel (8). Secure with Cam locks (D).




Tip

## Cam Locks


Cam Locks help securely join two pieces together. Follow these easy steps.



1: Insert Cam Bolt into bolt holes on the flat side. Don't over tighten!




2: Fit the proper holes on the edge of the other part over the Cam Bolts. You should be able to see the cam bolts through the larger hole on the side.



3: On the back of the Cam Lock will be a "C" shape. Insert the Cam Lock so the opening of the "C" fits over the Cam Bolt. Tighten with the screwdriver.


# Step 8

Things start coming together now! Attach the Left Side Panel (3) to the Lower Back Panel (8) with Cam locks (D). Then, rest the Front Rails (6) into the grooves of the Divider Panel (5) and secure them to the Left Side Panel (3) with Cam locks (D).




# Step 9

Repeat this on the other side and attach the Right Side Panel (4) to the Lower Back Panel (8) and the Front Rails (6) with Cam locks (D).




# Step 10

Attach the Bottom Panel (2) to the frame you just built with Cam Locks (D).



# Step 11


Stand the dresser upright and slide the Upper Back Panel (7) through the grooves in the side panels through to the groove in the Lower Back Panel (8).






# Step 12

Align the Cam bolts (C) on the Top Panel (1) with the holes in the panels and secure them with Cam locks (D). Look at that beautiful case you've built!




# Step 13

Let's make things a little more stable. Secure the top and bottom Front Rails (6) with the Screws (P).




# Step 14

Just a few cosmetic touches now, place the Stickers (E) over the visible Cam locks (D).




# Step 15

Secure the Plastic Wedges (M) with the Screws (N) against the Top Back Panel (7). This will eliminate racking and make the dresser extra strong!




# Step 16

Adjust the levelers on the legs to make sure the dresser is sturdy. Tip: This is easier to do before the weight of the drawers is added.





# Step 17

Insert Wooden dowels (B) into the Left, Right, and Back Drawer Panels (12, 13, 14, 16, 17, & 18)




# Step 18


Line up the dowel and pin holes then flip the tabs on the backside of the Top Drawer Back Panels (12) secure.



## Quick Assembly Drawers




1. Make sure the quick assembly drawer pin is aligned with the corresponding hole.



2. Once the pin is inserted correctly, flip the metal lever in the opposite direction to ensure the panels are firmly locked together.

# Step 19


Repeat the previous step for the lower drawers.






# Step 20

Slide the Bottom Drawer Panels (19) into the grooves of all six drawers.




# Step 21

Attach the Top Drawer Front Panels (11) to drawer sides (13 & 14) by aligning the dowels and flipping the pin. Secure the Handles (F) to the front of the drawers using the Screws (G).





# Step 22

Repeat the previous step for the lower drawers with the Lower Drawer Front Panels (15).




# Step 23

Line up the drawer member with the cabinet member and slide in the drawers to complete your new dresser!



Tip




## Reinserting your Cabinet Glides together

Line up the Drawer Member so it is inside the guides of the Cabinet Member. Once the connection is made, push the drawer into place entirely. It may not be a smooth glide on your first try, but will improve after it's fully inserted.


# Step 24

To anchor your dresser to the wall, attach the Plastic Straps (S) to the back of the Top Panel (1) using the Screws (R).



# Step 25

To secure on the wall you will need to drill a hole into the wall just large enough to fit the Anchor (T). Once the hole is drilled insert the Anchor (T). Use the Screw (Q) to secure the other end of the Plastic Strap (S) into the Anchor (T).



## Warning

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.

# Final Assembly



**Congratulations on your new piece of furniture!**

We would love to hear about it and see it.  
Please leave us a review or post a picture with  
**#mywalkeredisonhome**

# Assembling furniture can be tricky sometimes.

Our customer service team, located in Utah, is here for product information, help assembling a product, or for any other customer support issue

Call us at **801-433-3008**

Email us at [service@walkeredison.com](mailto:service@walkeredison.com)

Visit our Customer Service website at  
[walkeredison.com/pages/customer-service](http://walkeredison.com/pages/customer-service)

We are available to help Monday -Thursday 8am-5pm, Friday  
8am-3pm MST

For details on Assembly Videos, Assembly Instructions,  
Replacement Parts, and Customer service,  
**SCAN HERE**

