INSTALLATION INSTRUCTIONS

LED Flush Mount

Please read carefully and save these instructions, as you may need them at a later date. CAUTION

WARNING:Risk of Fire.Min90°C supply conductors.Consult a qualified electrician to ensure correct branch circuit conductor.

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.)standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

ASSEMBLY AND INSTALLATION

- 1. Shut off the power at the circuit breaker and remove existing fixture, including the crossbar.
- 2. Remove the mounting screw from the fixture.
- 3. Secure the mounting plate to the outlet box using junction box screws. The side of the mounting bar marked "GND" must face out.
- 4. Connect the Driver input wires to outlet box wires, making sure that all wire connectors are secured. If your outlet box has a green or bare copper ground wire, connect the fixture's ground wire to it. Otherwise, connect the fixture's ground wire directly to the back plate using the green screw provided. After wires are connected, tuck them carefully inside the outlet box.
- 5. Push canopy to ceiling, carefully passing mounting screws through holes. Secure the canopy to the mounting bar using the mounting screw.

DIMMING

This fixture features electronic low voltage 0-10V dimming capabilities. To utilize 0-10V dimming: use wire purple (dim+), gray (dim-), black (hot), white (neutral) and bare copper ground wire (ground).

compatible with:Lutron:DVSTV / NTSTV / MS-Z101 , Leviton:IP710-LFZ

