


**WE** Walker  
Edison  
furniture company

Item #: BWQCHEV  
Assembly Instructions




*For the most current instructions, additional assembly tips, to report damage or request parts, please visit our website at [www.walkerredison.com](http://www.walkerredison.com).*

Keep these instructions for future reference.


Revised 03/2018

# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. A Phillips head screwdriver is required for the assembly of this product .












- VI. Power tools should not be used to assemble this product .






# Parts List



# Hardware List

A		Ø 1/4"x90 mm	Bolt	08 pcs
B		Ø 7.0x100 mm	Bolt	10 pcs
C		Ø 7.0x70 mm	Bolt	02 pcs
D		Ø 4.0x30 mm	Screw	18 pcs
E		Ø 3.0x16 mm	Screw	06 pcs
F		Ø 10x40 mm	Wood dowel	10 pcs
G		Ø 1/4"	Barrel nut	08 pcs
H			Bracket	01 pcs
I		M4	Hex key	01 pcs



Phillips head screwdriver required for assembly  
(not included)


Tape measure recommended for assembly  
(not included)

Mallet or hammer recommended for assembly  
(not included)

*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*


# Step 1

Insert wood dowel ( F ) into rails ( 8, 9 ) and slat legs ( 11 ).




# Step 2

Attach leg ( 1 ) to slat ( 2 ) using bolt ( B ).




## Step 3

Slide headboard ( 3 ) into slat ( 2 ) gently.  
Ensure headboard ( 3 ) is pressed firmly against leg ( 1 ).






## Step 4

Attach leg ( 4 ) to slat ( 2 ) using bolt ( B ).  
Secure headboard ( 3 ) to slat ( 2 ) using screw ( D ).




# Step 5

Attach headboard cap ( 5 ) to headboard ( 3 ) using bolt ( B ). Ensure headboard cap ( 5 ) sits flush on top of headboard ( 3 ).





# Step 6



Attach legs ( 6, 7 ) to slat ( 8 ) using bolt ( B ). Attach bracket ( H ) to pre-drilled holes on the slat ( 8 ) using screw ( E ).



**Step 7** Insert barrel nut ( G ) into pre-drilled holes on rails ( 9 ).  
 Attach rails ( 9 ) to headboard ( 3 ) using bolt ( A ).  
 Bolt ( A ) will screw into barrel nut ( G ).




**Step 8** Insert barrel nut ( G ) into pre-drilled holes on rails ( 9 ).  
 Attach rails ( 9 ) to legs ( 6, 7 ) using bolt ( A ).  
 Bolt ( A ) will screw into barrel nut ( G ).






## Step 9

Attach slat legs ( 11 ) to slat support beam ( 10 ) using bolt ( C ).




## Step 10

Attach slat support beam ( 10 ) to bracket ( H ) using screw ( E ).




# Step 11

Attach slat support (12) to rails (9) and slat support beam (10) using screw (D). Ensure slat are spaced 3 inches from headboard (3).



# Step 12



Final Assembly.