


# ASSEMBLY AND INSTALLATION INSTRUCTIONS

P0153 / P0154

**WARNING:** TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER WHILE INSTALLING OR SERVICING THIS FIXTURE.

**NOTES:** 1. Before installing, consult local electrical codes for wiring and grounding requirements.  
2. READ AND SAVE THIS INSTRUCTION.

## Hardware Package (included):



## Installation Steps

Turn off the power at fuse or circuit box.

### 1. Rod Connections:

- Thread the fixture wire from the fixture through the lower rod, then secure the lower rod onto fixture using the threaded pipe.
- Thread the fixture wire through the middle rod, and then secure the middle rod onto the lower rod using the threaded pipe.
- Thread the fixture wire through the upper rod and the hook, then secure the upper rod onto the middle rod using the threaded pipe, attach the hook onto the upper rod using the threaded pipe.

**The height can be adjustable to 15"~57", by using the rods.**

- Thread the fixture wire through canopy, then hook the rod assembly to the loop.

- Unscrew two ball nuts, remove mounting strap from canopy

- Attach the mounting strap to outlet box by using two mounting screws.

- Pull out the source wires from the outlet box. Make wire connections using wire nuts as follows:

- Connect the smooth-coated wire (marked) from the fixture to the black wire from the power source.
- Connect the ribbed-coated wire (unmarked) from the fixture to the white wire from the power source.
- Attach the fixture grounding wire to the mounting strap with the green grounding screw. Then connect it to the house grounding wire with a wire nut.


Carefully put the wires back into the outlet box.

- Attach the canopy to the mounting strap by inserting the fixture mounting screws, and secure it with two ball nuts.

- Attach bulb(not included) to the socket. See relamping label at socket area or packaging for maximum allowed wattage.

- Attach the glass shade to the fixture, secure it with three set screws.


Turn on the power at fuse or circuit box.



The following parts are available for re-order if damaged or missing.

**Spare Parts List:**

			<p>→ Assembly Kit            5233MM (1 SET) for P0153            5234MM (1 SET) for P0154</p> Glass Shade (1PCS) 9681CS (1PCS) for P0153 9680MI (1PCS) for P0154	 Set Screw 5237SS(3PCS) for P0153 5238SS(3PCS) for P0154
Mounting Strap (A)	Mounting Screw (B)	Green Grounding Screw (C)		
Fixture mounting Screw (D)	Lock Nut (E)	Wire Nut (F)	Ball Nut (G)	
12"Rod 3017RD (3PCS) for P0153 3020RD (3PCS) for P0154	6"Rod 3016RD(1PCS) for P0153 3019RD(1PCS) for P0154	3"Rod 3015RD(1PCS) for P0153 3018RD(1PCS) for P0154		



A: 6-1/4"  
 B: 15"~57"