## **Pull Down Kitchen Faucet Installation**

## INSTALLATION MANUAL Tools You Will Need:



Adjustable wrench





## **Before the Installation**

1. Check the package and confirm all parts are included. If any part is missing or damaged, please contact us.

- 2. Do not disassemble the main body, as it has been installed & commissioned correctly & precisely before leaving the factory.
- 3. Shut off the main water supply prior to beginning installation.
- 4. Do flush the water supply lines to remove any dirt and debris before installation (IMPORTANT).

5. Make sure to connect the hot/cold inlet pipe correctly. If standing in front, connect hot water pipe to the left and cold water pipe to the right.

6. After the installation, check for leaks and make sure every joint is safely sealed.

## **Cleaning and Maintenance**

- 1. Rinse with clean water and dry with a soft cloth.
- 2. Do not use any detergent, acid, polisher, abrasives, or harsh cleaners.
- 3. Do not use cloth with a coarse surface.



- Remove the mounting nut (A), metal washer (B), and rubber washer (C) from the threaded pipe (D). Fit the O-ring (E) into the bottom groove of the faucet body (F).
- 2. Insert the faucet body (F) into drilled hole of the countertop. (NOTE: Escutcheon is needed for 3-hole installation.) Install rubber washer (C), metal washer (B) and mounting nut (A) back to the threaded pipe (D). Adjust the faucet body (F) correctly and secure with mounting screws (G) tightly.

 Add the rubber washer (H) and screw the hose (I) into the inlet of the faucet body (F).







- 4. Screw waterlines (J) into corresponding inlets of the faucet body (F). Place the weight ball (K) onto hose (I) and tighten the screws (L). (IMPORTANT: The weight ball should be positioned at the marked place as shown above to allow the spray head (M) to retract back in place.)
- Connect waterlines (J) to angle stops. Turn on the angle stops and check for leaks (DO NOT TURN FAUCET ON).
- Remove spray head (M) and turn faucet on for 1 minute to flush any debris.