


**W** Walker<sup>®</sup>  
Edison  
furniture company

Item # : W58BDSD  
Assembly Instructions




*For the most current instructions, additional assembly tips, to report damage or request parts,  
please visit our website at [www.walker-edison.com](http://www.walker-edison.com).*


Revised 08/2017

# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .





- VII. Power tools should not be used to assemble this product .




# Parts List



# Hardware List


A		Ø8x30mm	Wooden dowel	30 pcs
B			Cam bolt	26 pcs
C		Ø15x11mm	Cam lock	26 pcs
D		Ø6x50mm	Bolt	4 pcs
E			Hinge	4 pcs
F		Ø3x12mm	Screw	24 pcs
G			Handle	2 pcs
H		Ø4x22mm	Bolt	4 pcs
J		Ø8x5x16mm	Shelf support pin	12 pcs
K			Plastic wedges	12 pcs
L		Ø3x17mm	Screw	12 pcs
M		30x20mm	Metal piece	2 pcs
N		Ø3x12mm	Screw	2 pcs
P			Door stopper	2 pcs
Q		Ø3x15mm	Screw	4 pcs
R			Sticker	26 pcs
S		Ø4mm	Wrench	1 pc
T			Glue tube	2 pcs
U		Ø4x45	Screw	3 pcs



Philips head screwdriver required for assembly  
(not included)


*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

# Step 1




Attach cam bolts (B) to parts (1) and (2).

# Step 2




Attach cam bolts (B) to part (8). Insert wooden dowels (A) to parts (9, 10) and (19).

# Step 3




Insert wooden dowels (A) into designated areas in parts (3, 4, 5, 6) and (7). Attach cam bolts (B) to parts (3, 4, 5, 6).

# Step 4




Attach parts (3) and (5) to part (7), and then attach cam locks (C) to fully assembled part (7).

# Step 5





Attach parts (4) and (6) to the other part (7), and then insert cam locks (C) to the fully assembled part (7).

# Step 6




Attach cam locks (C) to parts (13) to panel (2). Attach slat (19) to panel (2) by using screw (U) as guides.

# Step 7





Attach cam locks (C) to part (9) to connect part (8), and to part (10) to connect to the other part (8).

# Step 8





Use the wrench (S) to use bolts (D) to connect parts (9) and (10) to part (2).

# Step 9




Use cam bolts (C) to connect parts (3) and (5) to part (2).

# Step 10




Use cam bolts (C) to connect parts (4) and (6) to part (2).

# Step 11




Slide parts (14) and (17) into designated area.

# Step 12




Use cam bolts to connect part (1) to the frame assembly as shown in the diagram.

## Step 13




Attach the plastic wedges (K) by using the screws (L) as shown in the diagram.

## Step 14




Attach door stopper (P) to designated areas by using screws (Q).

## Step 15




Place stickers (R) over cam locks as desired.

## Step 16




Insert shelf supports (J) and place shelves (15,16) and (18) as shown in the diagram.

## Step 17




Attach hinges (E) to the doors (11,12) by using screws (F).

## Step 18




Attach handles (G) to the doors (11,12) by using screws (H). Attach metal stopper (M) using screw (N).

## Step 19



Attach hinges (E) by using screws (F) as shown in the diagram.

## Step 20



### Final Assembly