


CONVENIENCE CONCEPTS

121909

NEWPORT BISTRO CONSOLE



Assembly instructions

We have designed our furniture with you, the customer in mind. Our clear, easy to follow, step by step instructions will guide you through the project from start to finish. Feel confident that this will be a fun and rewarding project. The final product will be a quality piece of furniture that will go together smoothly and give you years of enjoyment.



Please do not return to the store

Broken or missing Hardware?


Need help with Assembly?

If you have any questions just call 1-800-468-6447 or email us at

parts@convenience-concepts.com

PARTS IDENTIFICATION

ITEM#:121909


















Please count and verify all parts before assembly






(1) Top Panel	1pc	(5) Left Lower Leaning Shelf	1pc
(2) Back Panel	1pc	(6) Right Lower Leaning Shelf	1pc
(3) Left Upper Leaning Shelf	1pc	(7) Bottom Panel	1pc
(4) Right Upper Leaning Shelf	1pc		

HARDWARE IDENTIFICATION

ITEM#:121909

A		Cambolt	L29	2pcs
B		Camlock	Ø15mm	2pcs
C		Dowel	Ø8x25	4pcs
D		Large screw	Ø4x50	2pcs
E		Flat Head Screw	M6x25	3pcs
F		Large Wood Screw	Ø7x48	13pcs
G		Small Wood Screw	Ø7x38	2pcs
H		Medium screw	Ø4x30	6pcs
I		Foot Pin		4pcs
J		Sticker	Ø20	8pcs
K		Anti-tip Hardware		1pc
L		Small Screw	Ø4x25	1pc
M		Wall Screw	Ø5x40	1pc
N		Plastic Anchor	Ø8x40	1pc
O		Glue		1pc


Assembling the unit with camlocks and wood dowels.

				
Insert camlock, camlock must face bolt hole	Gently screw cam dowel into the threaded anchor	lightly glue one end of wood dowel and tap into hole.	lightly glue dowel and connect to second panel by inserting dowels into holes	Gently screw the cam clockwise into locked position. Do not overtighten.

Step1


PAGE: 4 of 6

1. Lightly glue dowels (C) and insert into leaning shelf (4,6).
2. Attach leaning shelf (3) to leaning shelf (4) using wood screw (F) as shown.
3. Attach leaning shelf (5) to leaning shelf (6) using wood screw (F) as shown.



Step2


1. Lightly glue dowels (C) and insert into leaning shelf (3).
2. Attach leaning shelf (3) assembly to leaning shelf (6) using wood screw (6) as shown.
3. Place sticker over holes as shown.



Step3


PAGE: 5 of 6

Attach bottom panel (7) to leaning shelf (5,6) using screws (D) as shown.




Step4

1. Lightly glue dowels (C) and insert into back panel (2).
2. Attach back panel (2) to leaning shelf assembly(4,5,6,7) using screws as shown.




Step5

PAGE: 6 of 6



1. Lightly glue dowels (C) and insert into top panel (1).
2. Attach cambolts (A) to top panel (1).
2. Attach top panel (1) to assembly and back panel (2) using screws and camlocks as shown.

Step6



1. Attach bracket(K) to top panel using small screw (L).
2. Drill a hole into the wall. Tap plastic anchor (N) into the hole in the wall.
3. Attach wall screw (M) through bracket (K) into plastic anchor(N).